

INSTRUCTIONS FOR INSTALLATION AND SERVICING


THERMOcompact VU 142/1 E

THERMOcompact VU 182/1 E

THERMOcompact VU 242/1 E

THERMOcompact VU 282/1 E

Wall hung room sealed fan assisted
system boilers



| | Page | | Page |
|--|-----------|-------------------------------------|-----------|
| 1. Introduction | 3 | 6. Servicing | 30 |
| | | 6.1 Initial inspection | 30 |
| 2. Boiler Specification | 4 | 6.2 Routine maintenance | 31 |
| 2.1 Technical Data | 4 | 6.3 Re-commissioning the boiler | 32 |
| 2.2 Dimensions | 5 | | |
| 2.3 Boiler connections | 5 | 7. Parts replacement | 33 |
| 2.4 Function diagram | 6 | 7.1 Initial preparation | 33 |
| | | 7.2 Fan | 35 |
| 3. General Requirements | 7 | 7.3 Air pressure switch | 35 |
| 3.1 Related documents | 7 | 7.4 Burner | 36 |
| 3.2 Boiler location | 7 | 7.5 Electrodes | 36 |
| 3.3 Gas supply | 8 | 7.6 Temperature sensor (NTC) | 37 |
| 3.4 Flue system | 8 | 7.7 Gas valve | 37 |
| 3.5 Air supply | 10 | 7.8 Heat exchanger | 38 |
| 3.6 Electricity supply | 10 | 7.9 CH expansion vessel | 39 |
| 3.7 Guide to system requirements | 10 | 7.10 Transformer | 40 |
| | | 7.11 Overheat thermostat | 40 |
| 4. Boiler installation sequence | 13 | 7.12 Pump | 40 |
| 4.1 General | 13 | 7.13 Automatic air release | 41 |
| 4.2 Boiler delivery | 13 | 7.14 Automatic bypass | 41 |
| 4.3 Preparation of boiler location | 14 | 7.15 Pressure and temperature | |
| 4.4 Installing the flue system | 16 | gauge | 42 |
| 4.5 Mounting the boiler | 16 | 7.16 Differential pressure switch | 42 |
| 4.6 Connecting the flue assembly | | 7.17 Circuit boards | 43 |
| to the boiler | 17 | | |
| 4.7 Electrical installation | 19 | 8. Fault finding | 44 |
| 4.8 Controls | 20 | 8.1 Introduction | 44 |
| | | 8.2 Logical fault finding procedure | 44 |
| 5. Commissioning | 23 | 8.3 Fault finding charts | 45 |
| 5.1 Preliminary electrical checks | 23 | | |
| 5.2 Gas supply | 23 | 9. Electrical diagrams | 54 |
| 5.3 Filling the heating system | 24 | 9.1 Functional flow diagram | 54 |
| 5.4 Initial system flush ('cold') | 24 | 9.2 Wiring diagram | 55 |
| 5.5 Initial lighting | 25 | 9.3 Schematic appliance | |
| 5.6 Gas inlet working pressure | 26 | circuit diagram | 56 |
| 5.7 Main burner pressure | 26 | | |
| 5.8 Adjusting central heating | | 10. Short parts list | 57 |
| output (range rating) | 27 | | |
| 5.9 Functional checks | 28 | 11. Supplementary LPG | |
| 5.10 Checking flame | | information | 59 |
| supervision device | 29 | | |
| 5.11 Final system flush ('hot') | 29 | | |
| 5.12 Fitting case | 29 | | |
| 5.13 Handing over to user | 30 | | |

Leave these instructions with the user when the installation is completed.

1. Introduction

Note: This boiler must be installed and serviced by a competent person in accordance with the Gas Safety (Installation and Use) Regulations 1994. In the UK 'CORGI' Registered Installers undertake the work to a safe and satisfactory standard.

The THERMOcompact is a fully automatic, wall mounted, room sealed system boiler for central heating and domestic hot water (where a separate indirect hot water storage cylinder is also incorporated in the system).

The boiler has been designed for use with a sealed central heating system, and comes fully tested and assembled with a built-in circulating pump, bypass and expansion vessel.



THERMOcompact boilers carry 'CE' Mark. This demonstrates that the boilers fulfill the essential requirements of the Gas Appliance Directive (90/396/EEC) and the Gas Appliance (Safety) Regulations 1992.

The 'CE' Mark also demonstrates that the boilers comply with the requirements of the Electromagnetic Compatibility Directive (Directive 89/336/EEC), the Low Voltage Directive (73/23/EEC), the Boiler Efficiency Directive (92/42/EEC) and the Boiler (Efficiency) Regulations 1993.

The THERMOcompact meets the requirements of 'The Boiler (Efficiency) Regulations 1993 and therefore is deemed to meet the requirements of Directive 92/42/EEC on the efficiency requirements for new hot-water boilers fired with liquid or gaseous fuels.

The boiler is easily sited on any internal wall and can be installed with either a horizontal or vertical RSF (Room Sealed Fan assisted) flue. Flue extensions and additional bends and elbows are available for increased siting flexibility. (The boiler is not suitable for external installation).

If desired an inhibitor may be used in the system. Guidance on the use of inhibitors is contained in these instructions.

Natural Gas and LPG versions of the boiler are available.

The THERMOcompact has built-in diagnostic indicator lights which illuminate in sequence, giving information on the boiler status when operating and performance of key components to aid in commissioning and fault finding.

The data badge is fitted on the bottom of the combustion chamber.

See text of General Requirements for Installation Requirements or notes.

2. Boiler specification

2.1 Technical data

| | VU 142/1 E | VU 182/1 E | VU 242/1 E | VU 282/1 E | units |
|---|-----------------------------|-----------------------------|-----------------------------|------------------------------|-------------------|
| Countries of Destination | GB, IE | | | | |
| Maximum heat input | 17.3 (59,000) | 22 (75,100) | 29.3 (100,000) | 34.2 (116,600) | kW (Btu/h) |
| Heat output range | 7.2-14.0 (24,600-47,800) | 7.2-18.0 (24,600-61,400) | 9.6-24.0 (32,800-81,900) | 11.2-28.0 (38,200-95,500) | kW (Btu/h) |
| Inlet gas working pressure required (Natural Gas) | 20 | 20 | 20 | 20 | mbar |
| Gas supply (G20) Gross C.V. (s.t.) | 37,8 | 37.8 | 37.8 | 37.8 | MJ/m ³ |
| Gas burner pressure max. rate | 6.3 | 10.2 | 10.0 | 10.6 | mbar |
| Gas burner pressure ignition rate | 2.0 | 2.0 | 2.0 | 2.0 | mbar |
| Gas rate max (DHW) | 1.65 | 2.09 | 2.79 | 3.26 | m ³ /h |
| Main burner jet size | 12x7/120 | 12 x 7/120 | 16 x 7/120 | 18 x 7/120 | no. x size |
| CH flow temperature range | 40-90 | 40-90 | 40-90 | 40-90 | °C |
| Minimum CH water flow (for 20 °C rise) | 602 | 774 | 1,032 | 1,204 | l/h |
| Pump pressure available | 0.25 | 0.25 | 0.25 | 0.25 | bar |
| 12l expansion vessel pre-charge pressure | 0.75 | 0.75 | 0.75 | 0.75 | bar |
| Maximum CH system pressure | 3.0 | 3.0 | 3.0 | 3.0 | bar |
| Connections | | | | | |
| Heating flow / return | 22 | 22 | 22 | 22 | mm |
| Gas inlet | 15 | 15 | 15 | 15 | mm |
| Pressure relief discharge pipework (min) | 15 | 15 | 15 | 15 | mm |
| Weight | 39 | 42 | 47 | 48 | kg |
| Primary water content | 0.65 | 0.65 | 0.7 | 0.7 | litres |
| Electrical supply | | | | | |
| Voltage | 230/50 | 230/50 | 230/50 | 230/50 | V~/Hz |
| 2 x internal fuses | 2 | 2 | 2 | 2 | A |
| 1 x internal fuse | 1.25 | 1.25 | 1.25 | 1.25 | A |
| external fuse | 3 | 3 | 3 | 3 | A |
| Power input | 130 | 130 | 130 | 130 | W |

Supplementary LPG information on page 57.


2.2 Dimensions

(All dimensions in mm)

- 1a Air/flue duct to the rear
- 1b Air/flue duct to the side
- 2 Appliance bracket
- 3 Heating system return (22 mm)
- 4 Gas connection (15 mm)
- 5 Heating system flow (22 mm)
- 6 Pressure relief valve outlet (3/4 in BSP)


* with standard horizontal flue accessory.
(max. = 2965 mm with 2 extensions)

Note: VU 142/1 E, VU 182/1 E boilers only, may be installed with up to 4 air/flue duct extension accessories giving a maximum flue length of 4935mm.




2.3 Boiler connections

- 1 Compression union (flow of heating system)
- 2 Service valve (flow of heating system)
- 3 Compression Union (gas)
- 4 Gas service valve (supplied with the boiler)
- 5 Service valve (return of heating system)
- 6 Compression union (return of heating system)
- 7 Pressure relief valve



2.4 Function diagram

- 1 Air duct
- 2 Air pressure switch
- 3 Combustion chamber
- 4 Temperature sensor (NTC)
- 5 Ignition electrodes
- 6 Modulating burner
- 7 Overheat thermostat
- 8 Fully modulating automatic gas valve
- 9 Indicator lights (LED's)
- 10 Boiler flow temperature control
- 11 Main on/off control
- 12 Reset control
- 13 CH flow service valve
- 14 Gas service valve
- 15 Flue gas duct
- 16 Fan
- 17 High efficiency heat exchanger
- 18 Flame sensing electrode
- 19 Differential pressure switch
- 20 Expansion vessel charging valve
- 21 Expansion vessel
- 22 Automatic air vent
- 23 Circulating pump
- 24 Temperature and Pressure gauge
- 25 Automatic bypass valve
- 26 Pressure relief valve
- 27 CH return service valve



3. General requirements

3.1 Related documents

The installation of the boiler must be in accordance with the relevant requirements of Gas Safety (Installation and Use) Regulations 1994, Health and Safety Document No. 635 (The Electricity at Work Regulations 1989), BS7671 (IEE Wiring Regulations) and the byelaws of the local Water Undertaking. It should also be in accordance with the relevant requirements of the Local Authority, Building Regulations, Building Standards (Scotland) Regulations and the relevant recommendations of the following British Standards:-

BS 5440: Flues and ventilation of gas fired boilers not exceeding 60 kW:

- Part 1: Flues
- Part 2: Ventilation

BS 5449: Specification for forced circulation hot water for domestic premises.

BS 5546: Specification for gas hot water supplies for domestic premises.

BS 6700: Services supplying water for domestic use within buildings and their curtilages.

BS 6798: Specification for installation of gas fired boilers not exceeding 60 kW input.

BS 6891: Specification for installation of low pressure gas pipework up to 28 mm (R1) in domestic premises (2nd family gas).

BS 7593: Treatment of water in domestic hot water central heating systems.

BRITISH GAS PUBLICATION DM2: Guide for Installation in Timber Framed Housing

Important

The appliance must be installed and serviced by a competent person as stated in the Gas Safety (Installation and Use) Regulations 1994

3.2 Boiler location

The location chosen for the boiler must permit the provision of a satisfactory flue termination. The location must also provide adequate space for servicing and air circulation around the boiler. The boiler may be installed in any room, although particular attention is drawn to the requirements of BS7671 (I.E.E. Regulations) and, in Scotland, the electrical provisions of the Building Standards (Scotland) Regulations, in respect of the installation of a boiler in a room containing a bath or shower.

(Note: Where a room sealed boiler is installed in a room containing a bath or shower, any electrical switch or boiler control utilising mains electricity should be so situated that it cannot be touched by a person using the bath or shower).

Where the installation of the boiler will be in an unusual location, special procedures may be necessary and BS 5546 and BS 6798 give detailed guidance on this aspect.

The boiler must be mounted on a flat, vertical wall, which must be sufficiently robust to take the weight of the boiler. The boiler may be installed on a combustible wall, subject to the requirements of the Local Authorities and Building Regulations.

A compartment used to enclose the boiler must be designed and constructed specifically for this purpose. (An existing cupboard or compartment may be used provided that it is modified for the purpose). Details of essential features of cupboard/compartment design including airing cupboard installations are given in BS 6798.

If the boiler is to be fitted in a timber framed building, it should be fitted in accordance with British Gas Publication DM2 'Guide for Gas Installations in Timber Framed Housing'.

3.3 Gas supply

The gas supplier should ensure the availability of an adequate supply of gas.

A gas meter may only be connected to the service pipe by the supplier of gas or their contractor.

An existing meter should be checked to ensure that it is capable of passing the rate of gas supply required.

Installation pipes should be fitted in accordance with BS 6891.

Pipework from the meter to the boiler must be of an adequate size. Do not use pipes of a smaller size than the boiler gas connection (15mm).

The complete installation must be tested for soundness and purged as described in BS 6891.

3.4 Flue system

The standard horizontal flue system (Art. No. 300 807) is suitable for installations up to 995 mm measured from the centre of the boiler flue outlet to the outside face of the wall (A, fig. 4). Flue extensions (Art. No. 300 802) are available to extend this length up to 2965 mm.

Note: VU 142/1 E, VU 182/1 E boilers only, may be installed with upto 4 air/flue duct extension accessories, giving a maximum flue length (A, fig. 4) of 4935mm.

Both 90° elbows (Art. No. 300 808) and 45° bends (Art. No. 300 809) are also available to increase siting flexibility.

A vertical flue system is also available (Art. No. 300 800).

THERMOcompact boilers may also be used in SE- duct applications (SE- duct flue kit available Art. No. 300810)

Refer to the flue installation instructions for full details.




fig. 4

GW 579/2

3.4.1 Flue Termination

1. The terminal must be positioned such that the combustion products can disperse freely at all times.
2. In certain weather conditions a plume of water vapour may be visible from the flue terminal. Positions where this could be a nuisance should be avoided.
3. If the terminal is fitted less than 2m above a balcony, above ground or above a flat roof to which people have access, then a suitable guard must be provided and fitted (available from Tower Flue Components, Tonbridge, TN9 1TB: reference TFC type K3).




Table 1:

Terminal position for fan-assisted flue (minimum distance - see fig. 5)

| | mm |
|--|------|
| A- Directly below an openable window or other opening (e.g. air brick) | 300 |
| B- Below gutters, soil pipes or drain pipes | 25 |
| C- Below eaves | 25 |
| D- Below balconies (below car port roof) | 200 |
| E- From vertical drain pipes and soil pipes | 25 |
| F- From internal or external corners | 25 |
| G- Above ground or balcony level | 300 |
| H- From a surface facing a terminal | 600 |
| I- From a terminal facing a terminal | 1200 |
| J- From an opening in a car port (e.g. door, window) into a dwelling | 1200 |
| K- Vertically from a terminal on the same wall | 1500 |
| L- Horizontally from a terminal on the same wall | 300 |
| M- Distance from adjacent wall for Vertical Flue | 500 |

fig. 5

Where a terminal is fitted less than 1m below a plastic gutter or less than 0.5m below painted eaves or any other painted surface then a suitable shield at least 1m long should be fitted to protect the surface.

Note: Vertical flues must not terminate within 600 mm of an openable window, air vent or any other ventilation opening.

3.5 Air supply

Detailed recommendations for air supply are given in BS 5440: Part 2.

It is not necessary to have an air vent in the room or internal space in which the boiler is installed.

3.5.1 Cupboard or compartment air supply

THERMOcompact Room Sealed System Boilers are very high efficiency appliances.

As a consequence the heat loss from the appliance casing during operation is very low. For cupboard and compartment installations it is therefore not necessary to provide any high or low level permanent air vents for cooling purposes.

3.6 Electricity supply

A 230 V~ 50Hz single phase electricity supply fused to 3 amps must be provided in accordance with the latest edition of BS7671 (I.E.E. Wiring Regulations) and any other local regulations that may apply.

THIS APPLIANCE MUST BE EARTHED.

The method of connection to the mains electricity supply must provide a means of completely isolating the boiler and its ancillary controls. Isolation is preferably by the use of a fused three pin plug and unswitched shuttered socket outlet, both complying with the requirements of BS 1363. Alternatively, a 3 Amp fused double-pole switch with a 3mm contact separation on both poles may be used.

3.7 Guide to system requirements

3.7.1 Water circulation system

Detailed recommendations for the water circulation system are given in BS 6798 and BS 5449: Part 1 (for small bore and micro bore central heating systems).

Pipework not forming part of the useful heating surface should be insulated to help prevent heat loss and possible freezing, particularly where pipes are run through roof spaces and ventilated underfloor spaces.

Draining taps must be located in accessible positions which permit the draining of the whole system including the boiler and the hot water system. Draining taps should be at least 1/2 in. BSP nominal size and be in accordance with BS 2879.

The boiler is suitable for use with minibore or microbore systems. Copper tubing to BS 2871: Part 1 should be used for water carrying pipework. All capillary joints in the DHW pipework must be made with lead free solder.

Particularly where a new boiler is to be fitted to an existing system, it is good practice that the system is thoroughly cleansed. This cleansing should take place prior to the fitting of the new boiler and be in accordance with BS 7593.

For advice on the application of system cleansers contact Sentinel, Betz Dearborn Ltd, Widnes, Cheshire, WA8 8UD.
Tel: 0151 4951861.

3.7.2 Filling and make up



The system should be filled with water via a separate filling point fitted at a convenient position on the heating circuit. Where local Water Authority Regulation allows, a temporary connection to the mains may be used (fig. 6). The connection must be removed when filling is completed. Where local Water Authority Regulation does not allow temporary connection, a sealed system filler pump with break tank must be used. (Alternative methods of filling sealed systems are given in BS 5449).

3.7.3 Pressure relief valve

A pressure relief valve is provided ready assembled within the boiler (6, fig. 7). This safety device is required on all sealed C.H. systems and is pre-set at 3 bar and provided with a 3/4 in. BSP connection for a discharge pipe, which must be of no less than 15mm diameter.

3.7.4 Pressure and temperature gauge

This is factory fitted to the boiler and indicates the primary circuit pressure to facilitate filling and testing, as well as showing the temperature of the central heating system water.



3.7.5 Expansion vessel

An expansion vessel is incorporated into the boiler. The expansion vessel supplied with VU 142/1 E is suitable for a sealed heating system with a maximum water content of 100 litres. The expansion vessel supplied with VU 182/1 E, VU 242/1 E, VU 282/1 E is suitable for a sealed heating system with a maximum water content of 135 litres.

If the nominal capacity of the built in expansion vessel is not sufficient for the heating system (for instance in case of modernisation of old open systems) an additional expansion vessel can be installed external to the boiler. It should be fitted in the return pipe as close as possible to the boiler in accordance with BS 5449: Part 1.

Guidance on the sizing of an additional expansion vessel is given in Table 2.

3.7.6 Circulating pump

The circulating pump is included in the boiler. The pump head available for the heating system is shown in fig. 8.

3.7.7 System by-pass

An automatic system by-pass is included within the boiler. The boiler is suitable for use in systems with thermostatic radiator valves and no additional by-pass is required.

3.7.8 Venting

The boiler is fitted with an automatic air vent. Additional provision should be made to enable the heating system to be vented during filling and commissioning either by automatic air vents or manually.

Table 2: Sizing of Additional Expansion Vessel

| Safety valve setting (bar) | 3.0 | |
|--|-------------------|-------|
| Initial system pressure (bar) | 1.0 | 1.5 |
| Total water content of system | VESSEL VOLUME (L) | |
| litres | | |
| 25 | 2.7 | 3.9 |
| 50 | 5.4 | 7.8 |
| 100 | 10.9 | 15.6 |
| 125 | 13.6 | 19.5 |
| 150 | 16.3 | 23.4 |
| 175 | 19.1 | 27.3 |
| 200 | 21.8 | 31.2 |
| 225 | 24.5 | 35.1 |
| 250 | 27.2 | 39.0 |
| 275 | 30.0 | 42.9 |
| 300 | 32.7 | 46.8 |
| 325 | 35.7 | 50.7 |
| 350 | 38.1 | 54.6 |
| 375 | 40.9 | 58.5 |
| 400 | 43.6 | 62.4 |
| 425 | 46.3 | 66.3 |
| 450 | 49.0 | 70.2 |
| 475 | 51.8 | 74.1 |
| 500 | 54.5 | 78.0 |
| For system volumes other than those given above, multiply the system volume by the factor across | 0.109 | 0.156 |




fig. 8

GW 402/2

4. Boiler installation sequence

4.1 General


The boiler should be mounted on a flat and vertical area of wall of sufficient area for the boiler plus the required minimum clearances for installation and servicing (fig. 9). These are shown on the installation template supplied with the boiler and are:

- 5 mm either side of the boiler
- 100 mm below the boiler*
- 165 mm on top of the boiler
- 500 mm in front of the boiler **

* 150 mm where optional pre-installation connecting group (Art. no. 8016) is used.

** This clearance is only required to enable easier access to the boiler for servicing and may be provided by an openable door, etc.

Note: If the boiler is to be fitted in a timber framed building, it should be fitted in accordance with British Gas publication reference DM2 'Guide for gas installations in timber framed housing.'



4.2 Boiler delivery

The THERMOcompact is delivered in two packs:

- a. the carton containing the boiler
- b. separately boxed flue accessory, either:
 - 1m horizontal flue accessory (Art. No. 300 807); or
 - vertical flue accessory (Art. No. 300 800)

4.2.1 Installation accessories

Table 3 lists the accessories which are available for the THERMOcompact system boilers.

4.2.2 Unpack the boiler (fig. 10)

Open the boiler carton and remove:

- a. protective cardboard sheet
- b. top and bottom decorative panels
- c. polystyrene packaging

Note: Care should be taken not to scratch the white surface of the boiler casing.

Packed in the boiler carton are the following:

- boiler installation template
- boiler hanging bracket
- gas service valve
- fixing screws and wallplugs
- installation and user instructions
- flue restrictor(s)

Table 3: Installation Accessories

| Accessories available | Art. No. |
|---|----------|
| 1. Horizontal air/flue duct and terminal accessory | 300 807 |
| 2. Vertical air / flue duct (including terminal) | 300 800 |
| 3. Pitched roof adjustable roof tile (for use with vertical air/flue duct) | 9076 |
| 4. Flat roof penetration collar (for use with vertical air/flue duct) | 9056 |
| 5. 1 m air /flue duct extension | 300 802 |
| 6. 2 m air / flue duct extension | 300 803 |
| 7. Additional 90° elbow for air / flue duct | 300 808 |
| 8. Additional 45° bends (pair) for air / flue duct | 300 809 |
| 9. Additional air / flue duct joint clamps (pair) | 300 806 |
| 10. Se- duct flue kit | 300 810 |
| 11. Internal flue fixing kit | 8098 |
| 12. Pre - installation connecting group | 8016 |
| 13. Vaillant boiler replacement connection accessory | 300 813 |
| 14. Pipe cover accessory | 8099 |
| 15. Plug in 7 day programmer. | 300 727 |

4.3 Preparation of boiler location

4.3.1 Select position of boiler.

Refer to Section 3.2 'Boiler Location' for information regarding siting the boiler. In general the boiler must be positioned such that:

- there is adequate space around the boiler for service and maintenance
- the boiler can be correctly flued, i.e. the flue terminal position is sited in accordance with Section 3.4.1 and the air / flue duct can be installed in accordance with the flue installation instructions supplied.
- all necessary pipework can be connected, including the pressure relief valve discharge pipe.




fig. 10

GW 601/1

4.3.2 Using the boiler template (fig. 11)

4.3.2.1 Once a suitable location has been chosen, fix the paper installation template on the wall ensuring that the centerline of the template is vertical using a spirit level or plumb line.

The template shows the positions of the fixing holes for the boiler hanging bracket (2) and the optional pre-installation connection group (3). The template also shows the position of the flue exit hole, for use where the air flue duct is to be installed directly to the rear of the boiler, e.g. where the boiler is installed on an outside wall and the flue terminates directly behind.

4.3.2.2 A Pre - installation connection group (Art. No. 8016) is available as an optional accessory. It is used to allow the installation of the central heating pipework without the need to have the boiler in position. Where an old existing Vaillant boiler is to be replaced, the boiler replacement accessory (Art. No. 300 813) can be used to allow easy connection of the new boiler to the existing connecting group. Refer to the instructions supplied separately with these accessories.

4.3.2.3 Mark on the wall the positions of the hanging bracket fixing holes (2). Drill two holes $\text{Ø} 10 \text{ mm}$ for the hanging bracket. (Note: Use the alternative fixing holes where necessary).


4.3.2.4 Rear exit flue.

Mark the position of the centre of the flue duct and its circumference, e.g. by drilling through the template (1, fig. 11).

4.3.2.5 Other flue options.

Refer to the installation instructions supplied with the flue accessory for detailed instructions on other flue options such as vertical RSF flues, flue runs to the side of the boiler and the use of additional flue elbows and bends etc.

4.3.2.6 Remove the template from the wall and plug the drilled holes using the wallplugs supplied.



4.3.3 Fitting the boiler hanging bracket.

Secure the hanging bracket to the wall using the screws supplied. (If the condition of the wall is poor it may be necessary to use additional or alternative fixings to ensure adequate support).

NOTE: If the boiler is to be fitted in a timber framed building ensure that the brackets are secured to a substantial part of the timber frame capable of taking the weight of the boiler.

4.4 Installing the flue system

At this stage install the flue system (refer to separate installation instructions supplied).

4.5 Mounting the boiler

4.5.1 Preparation

Remove the boiler from the carton. Lay the boiler on the floor and remove the white boiler bottom cover by removing two screws (1, fig. 49) and slackening two screws (2, fig. 49). Do not remove boiler side panels.

4.5.2 Fitting the boiler (fig. 13)

Lift the boiler up to the wall so that it is slightly above the hanging bracket.

Note: Lift the boiler from under the front edge of the side panels. Do not lift the boiler by the control box. Do not attempt to lift the boiler without the side panels fitted.

Lower the boiler slowly onto the hanging bracket so that the cross member at the top rear of the boiler fully engages into the hanging bracket.

4.5.3 Pipework connections (fig. 14)

Figure 14 shows the central heating, (2,5) gas (1) and pressure relief valve (6) connections.

4.5.3.1 Central heating flow and return

Before connecting the heating circuit to the appliance, all pipework and radiators must be thoroughly flushed to remove any installation debris. Connect the flow and return pipes to the central heating service valves (2) and (5) on the appliance using the 22mm compression connections.

4.5.3.1.1 Top pipework connection

If it is desired to run heating pipework to above the boiler, the purpose provided voids in the left and right sides of the boiler casing may be used (see fig. 15).

Note: To allow fitting of the bottom boiler cover, the left hand tab (2, fig. 15) should be folded upwards where pipes are fitted in the left hand void.

Where pipes are installed in these voids, a method of disconnection e.g. a compression connector (1, fig. 15) must be provided to allow easy removal of the boiler from the wall, if required.

4.5.3.2 Pressure relief valve discharge

The appliance contains the pressure relief valve required for a sealed system (6, fig. 14). Connect a discharge pipe not less than 15 mm diameter to the outlet of this valve.

This discharge pipework should be as short as possible and installed with a continuous fall away from the boiler. The pipe should terminate in a position which ensures that any discharge of water or steam from the valve cannot create a hazard to persons in or about the premises, or cause damage to any electrical components or external wiring, and the point of discharge should be clearly visible. The discharge must not terminate above a window, an entrance or any type of public access. The installer must consider that the pipe could discharge boiling water.




fig. 13

GW 608/1GB




fig. 14

GW 996/1




fig. 15

GW 1001/1GBVC

4.5.3.3 Gas supply

The boiler is supplied with a 20 x 15 mm gas service valve (4, fig. 14). Fit the 20 mm compression fitting to the boiler gas inlet (1, fig. 14) and tighten. Install a gas supply pipe not less than 15 mm diameter and connect to the gas service valve. (Ensure the gas supply pipework is adequately sized such that a 20 mbar - (8" w.g.) - gas pressure is available at the boiler inlet at full flow rate). Tighten all union connections.

4.6 Connecting the flue assembly to the boiler

Note: A flue restrictor ring, marked **F1** is packed with the users and installation instructions (an additional ring is supplied with a VU 142/1 E, 182/1 E boilers, marked **F11**). The restrictor should be fitted to the flue outlet of the boiler as shown in figure 18, for the flue installations shown in table 4 below:

| boiler type | Horizontal flue lengths | | |
|-------------|-------------------------|------------------------|------------------------|
| | up to 1m | from 1m to 3m | over 3m |
| VU 142/1 E | use F11 | use F1 | Do not use restrictor. |
| VU 182/1 E | use F11 | use F1 | |
| VU 242/1 E | use F1 | Do not use restrictor. | |
| VU 282/1 E | use F1 | restrictor. | |

| boiler type | Vertical flue lengths* | |
|-------------|------------------------|------------------------|
| | up to 1m | over 1m |
| VU 142/1 E | use F11 | Do not use restrictor. |
| VU 182/1 E | use F11 | |
| VU 242/1 E | use F1 | |
| VU 282/1 E | use F1 | |

* Vertical flue lengths quoted are measured from the flue outlet on top of the boiler to the bottom of the vertical air/flue duct and terminal assembly (Art. No. 300 800).

(Note: Refer to the air/flue duct installation instructions for full details of installation of the air flue duct. This Section is included for further reference only, e.g. in case the boiler has to be removed from the wall.)




fig. 17

GW 592/1




fig. 18

GW 705/1




fig. 19

GW 593/1

4.6.1 Horizontal Flue

Remove two screws (1, fig. 17) and take off one half ring (2, fig. 17). If necessary, fit the flue restrictor ring (Note : It will be necessary to remove both half rings if the flue restrictor ring is to be fitted. The flue restrictor ring should be placed on top of flue outlet directly below the two half rings see fig. 18. One half ring should be replaced immediately).

Place a 63mm diameter x 35 mm wide flue duct clamp (4, fig. 19) loosely over the flue duct (1, fig. 19). Place the 63 mm diameter x 25 mm wide flue duct clamp (5, fig. 19) over the flue gas connection on the boiler.

Loosen screws on the 95 mm diameter x 55 mm wide clamp (6, fig. 21) and push over the air duct.

Remove screws and sealing washer on the 95 mm diameter x 25 mm wide clamp (3, fig. 21) and push onto the flue elbow on the side to be connected to the appliance. Ensure the clamp is clear of the end of the elbow.

Push the flue elbow into the clamp (2, fig. 20) connected to the appliance flue gas duct and tighten the securing screws lightly.

Ensure that the elbow and air/flue duct line up and are closely butted together. Pull the clamp (4, fig. 20) over the joint between the flue gas duct and flue elbow. Ensure that the air/flue duct and terminal are correctly positioned. Tighten the securing screws on both clamps.

Note : Excessive tightening of these screws is not necessary. Ensure that the air / flue duct and terminal assembly is not displaced though the wall. Check that the air duct of the terminal still projects by 90 mm through the wall.

Refit the half ring 2, fig. 21. Pull the 95 mm diameter x 25 mm wide clamp (3, fig. 21) over the joint between the flue elbow and half rings. Refit the screws and sealing washer and tighten lightly.

Pull the 95 mm diameter x 55 mm wide clamp (6, fig. 21) over the joint between the flue elbow and air/flue duct. Tighten the securing screws on both clamps.

Drill two holes, 3 mm diameter through both air duct clamps into the air ducts at the most convenient positions (5, fig. 21). Take care not to penetrate the inner flue duct. Screw the clamps to the air ducts using the self tapping screws provided.

4.6.2 Vertical Flue

Remove the two half rings (2, fig. 17) and, if necessary, fit the flue restrictor ring.

(Note: It will be necessary to remove both half rings if the flue restrictor ring is to be fitted. The flue restrictor ring should be placed on top of flue outlet directly below the two half rings (see fig. 18). One half ring should be replaced immediately).

Fit the 63 mm diameter x 68 mm wide flue duct sleeve (2, fig. 22) over the flue gas duct of the air/flue duct assembly.

Loosen the screws of the 95 mm diameter x 55 mm wide clamp (1, fig. 22) and push over the air duct of the air/flue duct assembly.

Lower the flue assembly until a gap of about 25 mm exists between the air duct of the air/flue duct and terminal assembly and the half rings on the appliance. The two ducts must not butt together.

Pull the sleeve (2, fig. 22) down over the flue connection of the appliance against the stop. Align the holes in the sleeve and boiler flue gas connector and secure with a self tapping screw (1, fig.23).

Note : The sleeve must not be screwed to the bottom of the flue gas duct of the air/flue duct assembly. This duct must be able to slide in order to absorb small movements of the roof structure.

Refit the two half rings. Pull the 95 mm diameter x 55 mm wide clamp down over the joint between the air/flue duct assembly and the half rings. Tighten the clamp screws (1, fig.24).




fig. 20




fig. 21




fig. 22




fig. 23




fig. 24

Drill two holes 3 mm diameter through the air duct clamp (2, Fig 24) ensuring that the drill does not penetrate the flue duct. Screw the clamp to the boiler half ring using the self tapping screws provided.

Note: The air duct clamp must not be screwed to the bottom of the air flue duct and terminal assembly. The air/flue duct and terminal assembly must be able to slide in the air duct clamp to absorb any slight movements in the roof structure.

4.7 Electrical installation

4.7.1 General electrical requirements

All electrical work shall be carried out by a competent person and shall comply with BS7671 (IEE Regulations).

The boiler is supplied for connection to a 230V~ 50Hz supply fused at 3A rating. Connection to the mains supply should be made via a fused 3 pin plug to an unswitched, shuttered socket, both complying with the requirements of BS1363. (Alternatively, connection may be made via a 3 Amp fused double pole isolator having a contact separation of at least 3mm in all poles and supplying the boiler and controls only).

The point of connection to the mains must allow complete electrical isolation of the boiler and its ancillary controls. It should be readily accessible and adjacent to the boiler. A 3 core flexible cord according to BS6500 tables 6, 8 or 16 (3x0.75 to 3x1.5 mm²) should be used.

Warning: This appliance must be earthed

4.7.2 Connecting to mains supply

Slacken front panel fixing screw (1, fig. 25) and lower front panel. Remove terminal box cover by undoing screw (1, fig. 26)

Connect the power supply cord as follows (see fig. 27):-
green / yellow (earth) wire....

boiler terminal \ominus
Blue (neutral) wire..... boiler terminal N
Brown (live) wire..... boiler terminal L

Note: Do not use boiler terminal connections 7-8-9

IMPORTANT Ensure that all cords pass through the terminal box entrance grommets and are securely fixed by the cable clamps. Ensure that the power supply cord is connected such that the current carrying conductors become taut before the earthing conductor should the supply cord slip from the cable clamp.

Refit the terminal box cover after completion of all electrical connection.




fig. 25

GW 927/1GBVC




fig. 26

GW 614/1




fig. 27

The cable clamp (1, fig. 28) is only meant as a mounting aid. A possible damage caused when mounting or removing it will not cause any malfunction of the appliance.




fig. 28

GW 1527/0

4.8 Controls

4.8.1 External electrical controls

The boiler terminals 3,4 and 5 are for connecting external controls such as a programmer, room thermostat, etc.

Terminals 3 and 4 are linked together when the boiler is supplied. If external controls are used, this link must be removed, and the controls connected across terminals 3 and 4.

Terminal 5 is an additional neutral connection for external controls.

Refer to Section 4.8.2 for full connection details.

4.8.2 Connection of external electrical controls

4.8.2.1 Connection details using the wiring centre built in to the THERMOcompact boiler.

The THERMOcompact boiler incorporates a built-in wiring centre allowing connection of system controls. Figure 29 shows connection details for a system utilising a 3 port mid position motorised valve, Figure 29A shows the connection details for a system utilising two 2 port motorised valves connected via the built-in wiring centre. (Important: the arrowed numbers indicate connection into the relevant terminal of the built in wiring centre which is the separate box located at the lower left side of the boiler).

4.8.2.2 Connection details using an external wiring centre.

If required, the boiler can be connected to the system controls using an external wiring centre. Figure 30 shows connection details for a system utilising a 3 port mid position motorised valve, Figure 30A shows the connection details for a system utilising two 2 port motorised valves connected via an external wiring centre. (Important: the arrowed numbers indicate connection into the relevant terminal of the external wiring centre).


4.8.2.3 Connection details for optional plug in 2 channel central heating programmer (Art. No. 300 727)

Refer to the separate installation instructions supplied with the 2 channel programmer for connection details.

Fig. 29


Connections details for control systems utilising 3 port motorized valve, connected via built-in wiring centre on THERMOcompact boiler

Diagram only applies to the specific controls mentioned




Connection details between programmer and built-in wiring centre (3port motorized valve systems)

ACL Drayton LP 241, LP 522, LP 722




ACL Drayton Tempus 3, Tempus 4, Tempus 6, Tempus 7



Danfoss Randall FP 15, FP 75


* Earth not required



Danfoss Randall Set 3E, Set 4E


Please Note Link L-2 2-5

* Earth not required




Honeywell ST 699, ST 799A

Please Note Link L to 5 and 8




Honeywell ST 6200, ST 6300, ST 6400




Horstmann S25, S27, Chanel Plus H21, H27, H121, H272

Please Note Link L-2 2-5

* Earth not required




Landis & Gyr RWB 2, RWB XP, RWB 200, RWB 252, RWB 270



Potterton Myson EP 2002, EP 3002, EP 6002

Please Note: Link L-5



4.8.3 Thermostatic radiator valves

The boiler has a built-in automatic bypass valve making it ideal for use in systems with thermostatic radiator valves (no separate system bypass is required).

4.8.4 Circulating pump

The boiler incorporates a built-in circulating pump that is fully pre-wired. (No additional wiring is necessary). The pump incorporates an automatic overrun period after the boiler switches off.

4.8.5 Anti-cycling 'economiser' control


The boiler incorporates a built-in anti-cycling control to ensure that energy wasteful short cycling of the boiler cannot occur. This control prevents the burner from re-igniting for a pre-set period of 5 minutes after boiler operation.

Note: To temporarily override the anti-cycling control, turn the main on/off control to the "off" position (0), and then back to the "on" position (I) after a few seconds.

4.8.6 Frost protection

The boiler has an internal frost thermostat which is designed for protection of the boiler.

To protect remote or exposed parts of the heating system or property additional frost protection measures must be taken such as the installation of an external frost thermostat. This frost thermostat should be connected across the boiler terminals 3 and 4, in parallel with any external heating controls.



Connection details between programmer and built-in wiring centre (2 port motorized valve systems)

| | | | | | | |
|---|---|---|----------|---|---|---|
| ACL Drayton LP 241, LP 522, LP 722 | N | L | 1 | 2 | 3 | 4 |
| | 5 | 3 | NOT USED | | 7 | 6 |

| | | | | | | | |
|---|---|---|---|----------|---|---|---|
| ACL Drayton Tempus 3, Tempus 4, Tempus 6, Tempus 7 | E | N | L | 1 | 2 | 3 | 4 |
| | ⊕ | 5 | 3 | NOT USED | | 7 | 6 |

| | | | | | | | |
|--|---|---|---|----------|---|---|---|
| Danfoss Randall FP 15, FP 75 Please Note: Earth not required | E | N | L | 1 | 2 | 3 | 4 |
| | ⊕ | 5 | 3 | NOT USED | | 7 | 6 |

| | | | | | | | | | |
|--|---|---|---|---|----------|---|---|----------|---|
| Danfoss Randall Set 2E, Set 3E Please Note: Link L-2 2-5 (Set 2E) or L-2, 1-5 (Set 3E) * Earth not required | E | N | L | 1 | 2 | 3 | 4 | 5 | 6 |
| | ⊕ | 5 | 3 | 7 | NOT USED | | 6 | NOT USED | |

| | | | | | | | | |
|--|---|---|---|----------|---|---|----------|---|
| Honeywell ST 699, ST 799A Please Note: Link L to 5 and 8 | L | N | 3 | 4 | 5 | 6 | 7 | 8 |
| | 3 | 1 | 6 | NOT USED | | 7 | NOT USED | |

| | | | | | | |
|--|---|---|----------|---|---|---|
| Honeywell ST 6200, ST 6300, ST 6400, ST 6450B | N | L | 1 | 2 | 3 | 4 |
| | 5 | 3 | NOT USED | | 7 | 6 |

| | | | | | | | | | |
|---|---|---|---|---|----------|---|---|----------|---|
| Horstmann 525, 527, Chanel Plus H21, H27, H121, H272 Please Note: Link L-2 2-5 * Please Note: Earth not required | E | N | L | 1 | 2 | 3 | 4 | 5 | 6 |
| | ⊕ | 5 | 3 | 7 | NOT USED | | 6 | NOT USED | |

| | | | | | | |
|--|---|---|----------|---|---|---|
| Landis & Gyr RWB 2, RWB XP, RWB 200, RWB 252, RWB 270 | N | L | 1 | 2 | 3 | 4 |
| | 5 | 3 | NOT USED | | 7 | 6 |

| | | | | | | | | |
|---|---|---|---|----------|---|---|---|---|
| Potterton Myson EP 2002, EP 3002, EP 6002 Please Note: Link L-5 | E | N | L | 1 | 2 | 3 | 4 | 5 |
| | ⊕ | 5 | 3 | NOT USED | | 7 | 6 | |

Figure 30:





Figure 30A:



5. Commissioning

5.1 Preliminary electrical checks

Check the electrical installation by carrying out short circuit, earth continuity and resistance to earth tests and a check for correct polarity.


5.2 Gas supply

The complete gas installation including the gas meter must be inspected, tested for soundness and purged in accordance with BS 6891.

The gas supply to the boiler can be purged by slackening the gas service valve beneath the boiler (1, fig. 31). Ensure that there is adequate ventilation, extinguish naked flames and do not smoke whilst purging.

After purging, the gas service valve connection must be re-tightened and tested for soundness.

(The boiler itself does not require purging as this will be done by the automatic burner sequence control).



5.3 Filling the heating system

The boiler and the heating system should be filled using a filling method as described in Section 3.7.2.

Ensure that the boiler CH service valves (2, fig. 31) are open.

Partially open the filling valve and allow water to enter the system.

Starting with the lowest radiator, open the radiator air release until water (clear of bubbles) is emitted.

Repeat this at all radiators until the complete system is full, all air locks have been cleared and the boiler pressure gauge reads 1.5 Bar. Release any air from the pump by slackening the centre screw (1, fig. 32).

The boiler is equipped with an automatic air release valve. To allow this to vent the boiler, the cap on top (2, fig. 32) must be slackened by 1-2 turns. (This cap must be left slackened during boiler operation to ensure any residual air or system gases are released).

Check the heating system and boiler connections are sound.


5.4 Initial system flush ('cold')

The whole of the heating system must be flushed out at least twice: once cold, and once hot as instructed later in Section 5.11.

Open all radiator or heating valves and boiler CH service valves (2, fig. 31) and drain the heating system and boiler completely from the lowest points of the system via 1/2in. BSP drain taps (opened full bore to remove any installation debris prior to lighting the boiler).

Refill the heating system as described in Section 5.3: Filling the heating system.

Check the operation of the pressure relief valve by rotating the knob on the valve.




5.5 Initial lighting

- Check that the boiler combustion chamber (5, fig. 33) is correctly fitted.
- Open the gas service valve (1, fig. 31)
- Check that the CH service valves (2, fig. 31) are open.
- Check that all external heating controls are calling for heat.
- Switch on the electricity supply to the boiler.
- Set the boiler flow temperature control (3, fig. 33) to '9'.
- Turn the boiler on/off control (1, fig. 33) to the "on" position (I).

The boiler will now operate. Allow the boiler to run for a few minutes to clear any air remaining in the primary circuit.

(If the boiler should fail to light after the second ignition attempt the 'lock out' indicator will illuminate - see fig. 39. This usually means that the gas supply is turned off, or is not purged of air. Check gas supply, and turn the reset control to the reset position - (I) - and repeat lighting procedure).

- Turn the boiler on/off control to the 'off' position (O).



5.6 Gas inlet working pressure

Check the gas inlet working pressure by slackening the sealing screw and attaching a U gauge to the test point (3, fig. 34) on the inlet to the gas valve. Fire the boiler by turning the boiler on/off control to the 'on' position (I). Check that the U gauge is reading 20 mbar (natural gas).

(If the pressure is not 20mbar this should be investigated before continuing with the commissioning procedure. Lower pressures than 20mbar are indicative of an incorrectly sized or partially blocked gas supply).

Turn the boiler on/off control to the 'off' position (O). Remove U gauge. Tighten the test point screw and test for soundness.

5.7 Main burner pressure

The burner pressure on this boiler has been factory set and does not require adjustment. The main burner pressure may be checked in the following way:

- Slacken the sealing screws and attach one arm of a U gauge to the burner test point (1, fig. 35). Remove plastic sealing plug and connect the other arm to the combustion chamber sensing tube (2, fig. 35).
- Ensure the boiler flow temperature control (3, fig. 33) is set to '9' and all external controls are calling for heat.
- Turn the boiler on/off control to the 'on' position (I). Break the in line connector to the NTC temperature sensor (3, fig. 35).
- Check that the burner pressure is as shown in Table 5. (If the burner pressure is not correct within the tolerance shown, contact Vaillant Ltd. Technical Department).
- Turn the boiler on/off control to the 'off' position (O).
- Remove U gauge. Tighten the sealing screw (1, fig. 34) and test for soundness. Reconnect NTC sensor (3, fig. 35). Refit plastic plug in chamber sensing tube (2, fig. 34).
- Reset the boiler flow temperature control to the required setting (see Section 5.13).
- Raise control box and secure in position using screw (1, fig. 25).





Table 5: Burner Pressure & Gas Rate

| | VU 142/1 E | VU 182/1 E | VU 242/1 E | VU 282/1 E |
|--------------------------------------|---|---|---|--|
| Maximum Burner Pressure (DHW) | 6.3 mb (±0.6 mb) | 10.2 mb (±1.0 mb) | 10.0 mb (±1.0 mb) | 10.6 mb (±1.0 mb) |
| Maximum Gas Rate | 1.65 m ³ /h (58.3 ft ³ /h) | 2.09 m ³ /h (73.9 ft ³ /h) | 2.79 m ³ /h (98.5 ft ³ /h) | 3.26 m ³ /h (115.1 ft ³ /h) |

5.8 Adjusting the central heating output (range rating)

The THERMOcompact is fully modulating and it is therefore not necessary to range rate the boiler. However, if desired, it is possible to range rate the boiler, as follows:

- Remove screw (1, fig. 36) and lower control panel.
- Slacken the sealing screw and attach one arm of a U gauge to the burner pressure test point (1, fig.35). Remove plastic sealing plug and connect the other arm to the combustion chamber sensing tube (2, fig.35).
- Remove screw (1, fig. 37) and remove terminal box cover to access the range rating potentiometer (2, fig. 38) beneath.
- Operate the boiler by turning the on/off control to the 'on' position (I) ensuring that the external controls are calling for heat and the boiler flow temperature control is set to 9.
- The boiler output can now be altered by inserting an electrician's screwdriver into the potentiometer (2, fig. 38)
- Turn the potentiometer fully anticlockwise to the stop.
- Slowly turn the potentiometer clockwise, whilst observing the U gauge.
- Stop turning the potentiometer when the burner pressure is at the correct setting for the output required (see table 6).
- Turn the boiler off.
- Remove U gauge. Tighten the sealing screw, (1, fig. 34) and test for soundness.
- Refit plastic plug in chamber sensing tube.
- After setting, refit cover screw (1, fig. 37) and re-secure control panel (1, fig. 36).






Table 6: Central Heating Output (Range Rating)


| Output to central Heating kW (Btu/h) | Range rating mbar | | | |
|--------------------------------------|-------------------|------------|------------|------------|
| | VU 142/1 E | VU 182/1 E | VU 242/1 E | VU 282/1 E |
| 28.0 (95.560) | - | - | - | 10.6 |
| 24.0 (81.900) | - | - | 10.0 | 8.0 |
| 21.0 (71.700) | - | - | 8.0 | 6.3 |
| 18.0 (61.500) | - | 10.2 | 6.1 | 4.8 |
| 15.0 (51.200) | - | 7.5 | 4.5 | 3.4 |
| 14.0 (47.800) | 6.3 | 6.3 | 4.0 | 3.0 |
| 12.0 (41.000) | 5.0 | 5.0 | 3.1 | 2.2 |
| 9.0 (30.700) | 2.9 | 2.9 | - | - |
| min 7.2 (24.570) | 2,0 | 2.0 | - | - |
| min. 9.6 (32.800) | - | - | 2.0 | - |
| min. 11.2 (38.240) | - | - | - | 2.0 |

5.9 Functional Checks

The Vaillant THERMOcompact is equipped with a set of diagnostic indicator lights to show the operational status of the boiler. A functional check of the boiler operation can be made using these indicator lights (fig. 39).

- Set the boiler on/off control to the 'on' position (I).
- The power on indicator will illuminate.
- Ensure external controls are calling for heat.
- The demand indicator will illuminate.
- Providing the boiler has not achieved its set temperature, and the anti cycling control is not activated, the boiler will start its lighting sequence. Once the fan and flue system have proved their satisfactory operation the fan operation indicator will light.
- The gas valve will open and sparking will commence at the burner. The ignition indicator will illuminate.
- As soon as the burner has ignited and the flame has been sensed the flame indicator will illuminate.
- By illuminating in this sequence the indicator lights have demonstrated correct operation of the boiler.

Note : Should the boiler fail to light it will attempt re-ignition after an approximate delay of 10 second, if the boiler fails to light at the 2nd attempt the burner lock out indicator will illuminate. This usually means that the gas supply is turned off or has not been purged of air. Check the gas supply, turn the control to the reset position (0) and repeat the lighting procedure.



5.10 Checking flame supervision device

Operate the boiler and turn off the gas supply at the boiler gas service valve. The boiler should attempt to re-light (sparking at ignition electrode visible through viewing window) for approximately 10 seconds, if ignition does not occur the boiler will re-attempt ignition after a further 10 second delay before shutting down. The lockout indicator light will illuminate. Open the gas service valve and turn the reset control (2, fig. 33) to the reset position (⬆). The boiler should now re-light.

5.11 Final system flush ('hot')

Allow the boiler and system to reach maximum temperature and check that the heating system is watertight. Turn the boiler off and rapidly drain both boiler and system while still hot. Refill the system and release all air as described in Section 5.3. Release water from the system until the system design pressure of 1.2 bar is attained. (The actual reading on the pressure gauge - (4, fig. 33) - should ideally be 0.5 Bar plus an additional pressure corresponding to the highest point of the system above the base of the boiler - 10 m head equals an additional 1 Bar reading on the pressure gauge. The minimum pressure should not be less than 1 Bar in any installation).

If the system is to be treated with an inhibitor it should be applied at this stage. Sentinel X 100 is suitable for this purpose and it should be applied in accordance with the manufacturers instructions.

Further information can be obtained from Sentinel, Betz Dearborn Ltd, Tel: 0151 4951861.

Disconnect the temporary filling connection.

5.12 Fitting case

Attach top door panel by slotting side clips (1, fig. 40) into holes in side panel and sliding panel down to secure. Attach bottom door panel by locating onto top hinge pin (2, fig. 41) and insert bottom hinge screw (1, fig. 41).

5.12.1 Door hinged at left hand side

If required the appliance lower door can be altered to hinge on the lefthand side.



Remove screws from bottom hinge pin (1, fig. 41) and transfer to left hand side panel.

Lift bottom of top hinge pin (2, fig. 41) away from casing to release retaining lug. Rotate top hinge through 90° to remove. Refit to left hand side casing.

Attach bottom door panel by locating onto top hinge pin (2, fig. 41) and insert bottom hinge screw (1, fig. 41) so that it locates into the door.

5.12.2 Fit bottom cover

Attach bottom cover to boiler by locating over front screws (2, fig. 49) and secure with rear screws (1, fig. 49).



5.13 Hand over to user

Set the boiler flow temperature control (3, fig. 42) to the desired setting. The following settings may be used as a guide:

| | |
|-------------------|-------|
| Spring and Autumn | 6 – 7 |
| Winter (normal) | 7 – 8 |
| Winter (severe) | 8 – 9 |

Note: Boiler flow temperature control settings below 6 will result in reduced domestic hot water temperatures.

Instruct the user in the safe and efficient operation of the boiler, in particular the function of:-

- the boiler on / off control
- the boiler flow temperature control
- the pressure gauge.

Show the user how to operate any external controls.

Explain to the user the importance of having the boiler regularly serviced by a competent servicing company. To ensure regular servicing, it is strongly recommended that arrangements are made for a Maintenance Agreement. Please contact Vaillant Service Solutions (tel: 0870 6060 777) for further details.

Leave the user instructions in the purpose provided pocket on the front of the control panel (2, fig 36).

Leave the installation and service instructions with the user.

6. Servicing

To ensure the continued safe and efficient operation of the boiler it is recommended that it is checked and serviced as necessary at regular intervals. The frequency of servicing will depend upon the particular installation conditions and usage, but in general once per year should be adequate. It is law that all servicing work is carried out by a competent person (CORGI registered).

IMPORTANT:

Before starting any maintenance work:

- Isolate the mains electricity supply by disconnecting the plug at the socket outlet (if there is an isolating switch only remove the fuse from the switch).
- Turn OFF the gas supply at the gas service valve fitted to the boiler.
- Always test for gas soundness and always carry out functional checks after any service work and after exchanging any gas carrying component.
- Always check earth continuity, polarity and resistance to earth with a multi-meter after any service work and after exchanging any electrical component.

Note: The boiler is fitted with a combustion analysis test point (6, fig. 42). A suitable combustion analyser can be connected to this point to establish the combustion performance of the boiler.

6.1 Initial Inspection

Before commencing any servicing or maintenance work, carry out an initial inspection of the system as follows:-

Inspect the flue, pipework and electrical connections for indications of damage or deterioration.

Inspect the air supply and ventilation arrangements of the installation, ensuring that the requirements of Section 3.5 are met.

Operate the boiler by turning on all external controls and turning the on/off control (1, fig. 42) to the 'on' position (I). Inspect the burner operation through the viewing window. Check that the flames are burning evenly over the full surface of the burner. Inspect for signs of excessive lifting or sooting.

Check the heating system, in particular the condition of the radiator valves and for evidence of leakage from the heating system pipework.




fig. 42

GW 999/1 GBVC


6.2 Routine maintenance

6.2.1 Remove front case

Remove bottom hinge pin screw (1, fig. 44) and pull door forward and down to release it from the top hinge pin (2, fig. 44).

Slide the top panel up to release retaining clips (1, fig. 45). Lift off top panel.

- Remove boiler bottom cover by undoing two screws (1, fig. 49) and slackening two screws (2, Fig. 49).



6.2.2 Turn off the boiler (fig. 43)


- Isolate the electrical supply to the boiler
- Turn off the gas service valve (2)
- Turn off boiler CH service valves (1 and 4)

6.2.3 Remove combustion chamber front cover (5, fig. 42)

Remove four screws (2, fig. 52) securing combustion chamber front cover

Lift combustion chamber clear of top retaining lugs and pull forward.


Remove combustion chamber cover by first bringing the left side forward to clear boiler casing.



6.2.4 Inspect main heat exchanger

Remove five screws securing heat exchanger front panel (1 and 3, fig. 46) and remove by gently pulling down and forward.

Inspect main heat exchanger and remove any deposits with a soft brush.



6.2.5 Inspect burner

With the combustion chamber front cover and heat exchanger front panel removed it is possible to inspect the burner. Any deposits should be removed with a soft brush. Check the condition of the ignition and monitoring electrodes.

6.2.6. Check expansion vessel

Note: It is not necessary to carry out this check every year - a check every three years should be sufficient.

Release the pressure from the boiler as described in section 7.1.2.

Remove valve cap from expansion vessel charge point (2, fig. 47a or b).




Check that internal charge pressure of expansion vessel is between 0.7 - 0.9 Bar. If pressure is lower than this the vessel should be re-pressurised using an air pump.

Refit valve cap (2, fig. 47a or b).

Open boiler service valves and re-pressurised the boiler and heating system if necessary (see section 5.3).

6.3 Re-commissioning the boiler

- Refit the heat exchanger front panel.
- Refit combustion chamber front cover ensuring that the seal is in good condition. Ensure that the cover is correctly fitted and a good seal is obtained.
- Turn on the gas and electricity supplies.
- Check soundness of internal gas connections.
- Carry out electrical safety checks (see section 5.1)
- Check water soundness
- Operate burner and check flame picture.
- Check for correct function of the boiler (see section 5.9).
- Check burner pressure as described in section 5.7 and boiler gas flow rate.
- Refit case (see Section 5.12)



7. Parts replacement

IMPORTANT:

Before starting any maintenance work:

- Isolate the mains electricity supply by disconnecting the plug at the socket outlet (if there is an isolating switch only, remove the fuse from the switch).
- When removing any water carrying components ensure that the control box cover and terminal box cover are in position and water is kept away from all electrical components.
- Turn OFF the gas supply at the gas service valve fitted to the boiler.
- Always test for gas soundness and always carry out functional checks after any service work and after exchanging any gas carrying component.
- Always check earth continuity, polarity and resistance to earth with a multimeter after any service work and after exchanging any electrical component.

7.1 Initial preparation


(These initial preparation procedures need only be carried out where specifically mentioned in the individual component replacement procedures).

7.1.1 Turning off the boiler (fig. 48)

- Isolate the electrical supply to the boiler
- Turn off the gas service valve (1)
- Turn off boiler CH service valves (2)

7.1.2 Releasing system water pressure and draining the boiler (fig. 48)

- Isolate electrical supply to boiler.
- Remove combustion chamber cover as in section 7.1.5.
- Turn off boiler CH service valves (2).
- Attach a length of rubber tube to draining points (3), and drain the water from the boiler into a suitable container by undoing the drain points one turn.
- When pressure gauge reads zero, open main heat exchanger air vent (5, fig. 55) to allow complete draining of the boiler. Close air vent before refilling the boiler.



7.1.3 Removal of front casing

7.1.3.1 Door (fig. 50)

- Remove bottom hinge pin screw (1) and pull the bottom door panel forwards and down to release it from top hinge pin (2).

7.1.3.2 Top panel (fig. 51)

- Slide top panel upwards to release retaining clips (1).

7.1.3.3 Bottom cover plate (fig. 49)

- Remove two screws (1) and slacken two screws (2).
- Slide cover forwards and drop down to remove

7.1.3.4 Reassembly

- Reassemble in reverse order.

7.1.4 Removal of side casings

- Remove front casing as in section 7.1.3.
- Remove screws (3, fig. 51)
- Remove screws (4, fig. 51) and retaining brackets.
- Slide side case panel upwards to release retaining clips (2, fig. 51) and lift off.
- Reassemble in reverse order

7.1.5 Removal of combustion chamber cover (fig. 52).





- Remove front casing as in section 7.1.3,
- Remove four screws (2) securing combustion chamber front cover
- Lift combustion chamber cover clear of top retaining lugs and pull forward
- Remove combustion chamber cover by first bringing the left side forward to clear boiler casing.
- Check condition of case seal and if necessary replace before refitting
- Reassemble in reverse order, ensuring that the combustion chamber front cover is correctly fitted and a good seal obtained.

7.1.6 Lower front control panel (fig. 52)

- Remove front casing as in section 7.1.3,
- Undo screw (1) and lower control box forward from top.


7.1.7 Removal of heat exchanger front panel.

- Remove the five screws (1 and 3, fig. 46) securing the heat exchanger and remove the panel by gently pulling down and forward.




7.2 Replacement of fan (fig. 53)

- Isolate the boiler from the electrical supply.
- Remove front casing as in section 7.1.3, and remove combustion chamber cover as in section 7.1.5.
- Disconnect the electrical connections from the fan.
- Remove the 2 fan securing screws (4) and remove fan.
- Reassemble in reverse order.
- Re-fit combustion chamber and front casing.
- Carry out electrical checks (see section 5.1).




7.3 Replacement of air pressure switch (fig. 54)

- Isolate the boiler from the electrical supply.
- Remove front casing as in section 7.1.3.
- Disconnect electrical connections to pressure switch
- Remove screw (1) and lift out pressure switch.
- Disconnect air tubes (2) from switch.
- Reassemble in reverse order.
- Carry out electrical checks (see section 5.1).




Note: Air tubes should be reconnected
P1 to white tube.
P2 to blue tube.
(P1 and P2 are marked on air pressure switch).




7.4 Replacement of burner

- Isolate the boiler from the electrical supply.
- Remove front casing as in section 7.1.3.
- Remove combustion chamber cover as in section 7.1.5
- Disconnect the ignition and flame sensing electrode leads (1, fig. 55).
- Remove two screws (2, fig 55) and pull burner forwards to remove.
- Reassemble in reverse order.
- Carry out electrical checks (see section 5.1) and check burner pressure (see section 5.7) and gas rate.



7.5 Replacement of electrodes

- Isolate the boiler from the electrical supply.
- Remove front casing as in section 7.1.3, and remove combustion chamber cover as in section 7.1.5
- Remove heat exchanger front panel as in section 7.1.7
- Pull off HT lead (ignition electrode) or sensing wire (flame sensing electrode) (1, fig 55)
- Depress spring retaining clip (1, fig 56) gently pull electrode up and clear of burner.
- To replace the electrode, depress spring retaining clip (1, fig 56) and insert electrode until the "V" locates in the cross support (2, fig 56)
- Carry out electrical checks (see section 5.1).





7.6 Replacement of NTC temperature sensor

Note: The NTC temperature sensor is an extremely reliable component and as such is unlikely to fail. Before changing the NTC please check that it is defective - see section 8 - fault finding.

- Disconnect boiler from electricity supply.
- Remove front casing as in section 7.1.3 and remove combustion chamber cover as in section 7.1.5
- Pull off connecting wire to sensor.
- Unscrew NTC sensor. (4, fig 60)
- Reassemble in reverse order.
- Carry out electrical checks (see section 5.1).

7.7 Replacement of gas valve

- Isolate the boiler from the electrical supply
- Remove the front casing as in section 7.1.3
- Lower front control panel as in section 7.1.6
- Turn off the gas service valve (1, fig. 48)
- Loosen screw (1, fig. 57) and pull off rectifier plug (2, fig. 57) from the gas operator.
- Pull off modulating coil wires (3, fig. 57).
- Disconnect air tube from gas operator (4, fig. 57).
- Remove two screws (5, fig. 57) at burner inlet connection.
- Remove screw (6, fig. 57) from gas valve inlet connection.
- Rotate gas valve to left and then lift to remove.
- Remove both inlet and outlet connections from the gas valve (1, fig. 58) by removing the eight securing screws (2, fig. 58) and refit to new gas valve using new seals provided.
- Reassemble in reverse order.
- Set burner pressure in accordance with instructions supplied with spare part.
- Carry out electrical checks (see section 5.1) and test all gas joints for soundness.





7.7.1 Replacement of modulating regulator

- Isolate the boiler from the electrical supply.
- Remove front casing as in section 7.1.3 .
- Lower front control panel as in section 7.1.6
- Turn off the gas service valve (1, fig. 48).
- Loosen screw (1, fig. 59) and pull off rectifier plug (2, fig. 59) from the gas operator.
- Pull off modulating coil wires (4, fig. 59).
- Remove modulating regulator by removing 2 screws (3, fig. 59) and pull regulator from gas valve body.
- Reassemble in reverse order.
- Set burner pressure in accordance with instructions supplied with spare parts.
- Carry out electrical checks (see section 5.1) and test all gas joints for soundness.

7.8 Replacement of main heat exchanger

- Turn off the boiler as in section 7.1.1.
- Remove front casing as in section 7.1.3 and remove combustion chamber cover as in section 7.1.5
- Remove heat exchanger front panel as in section 7.1.7
- Release CH water pressure and drain boiler as in section 7.1.2.
- Remove burner assembly as in section 7.4.
- Pull off wire from NTC (4, fig. 60)
- Disconnect flow and return connections (3, fig 60)
- Slide the heat exchanger forward to remove.
- Disconnect flow and return pipes from the heat exchanger by rotating at joints (bayonet fix)
- Reassemble in reverse order.
- Recommission boiler (see section 5).



7.9 Replacement of expansion vessel

In the unlikely event of a failure of the expansion vessel follow procedure 7.9.1 or 7.9.2 depending upon the installation circumstances.

7.9.1. Boiler installed with air/flue duct to left/right hand side, or vertical flue installation (where 600mm vertical clearance exists above the boiler).

- Remove front casing as in section 7.1.3
- Turn off the boiler as in section 7.1.1.
- Release CH water pressure and drain boiler as in section 7.1.2.
- Remove combustion chamber cover as in section 7.1.5
- Remove 2 screws (1, fig 47).
- Remove screw (1, fig. 54 b) to release air pressure switch - **VU 142/1 E only.**
- Slide expansion vessel upwards and out of boiler casing.
- Refit new expansion vessel ensuring that it correctly locates onto lower push fit spigot on boiler.
- Refill and repressurise the boiler (see section 5.4).

7.9.2 Boiler installed with air flue duct to the rear, or vertical flue installation (where less than 600mm vertical clearance exists above the boiler)



EITHER

Remove the boiler from the wall as follows:

- Remove front casing as in section 7.1.3
- Turn off the boiler as in section 7.1.1.
- Release system water pressure and drain boiler as in section 7.1.2.
- Lower front control panel as in section 7.1.6
- Disconnect external wiring from boiler wiring terminal box.
- Disconnect flow and return connections at compression connection above boiler service valves (1, fig. 62).and remove two screws securing retaining lug to appliance chassis (2, fig. 62)
- Disconnect gas connection at compression joint on top of gas service valve (3, fig. 62).
- Disconnect pressure relief valve discharge pipework from boiler.
- Disconnect the flue from the top of boiler as described in section 4.6.
- Remove boiler from wall.
- Remove screw (1, fig. 54 b) to release air pressure switch - **VU 142/1 E only.**
- Remove two screws (1, fig. 47) and slide expansion vessel upwards and out of boiler casing.
- Re-mount the boiler (see section 4.5 and 4.6).
- Re-commission the boiler (see section 5).

OR

A suitable replacement expansion vessel can be fitted externally to the boiler as described in Section 3.7.5 (if possible on the central heating return in an accessible position). In these circumstances, the replacement expansion vessel must be correctly sized ignoring the original expansion vessel which can be left in position on the boiler.



7.10 Replacement of transformer

- Isolate boiler from the electricity supply.
- Remove front casing as in section 7.1.3
- Lower front control panel as in section 7.1.6.
- Disconnect ignition leads (3, fig. 63) from rear of control box.
- Remove back of control box by undoing the 3 screws (1 and 2, fig. 63).
- Unplug transformer (4, fig 65) connecting lead from main switch board.
Move clips (3, fig. 65) to the left and remove transformer from control box.
- Reassemble in reverse order.
- Carry out electrical checks (see section 5.1).

7.11 Replacement of overheat thermostat

- Isolate the boiler from the electricity supply.
- Remove front casing as in section 7.1.3.
- Lower front panel as in section 7.1.6.
- Pull wires off overheat thermostat (2, fig 64).
- Unscrew overheat thermostat to remove.
- Reassemble in reverse order.
- Carry out electrical checks (see section 5.1).





7.12 Replacement of pump

- Remove front casing as in section 7.1.3.
- Turn boiler off as in section 7.1.1.
- Release pressure and drain boiler as in section 7.1.2.
- Lower front control panel as in section 7.1.6.
- Disconnect ignition leads (3, fig. 63) from rear of control box.
- Remove back of control box by undoing the 3 screws (1 and 2, fig. 63).
- Unplug pump wire from main switchboard, and remove earth lead from earth strip.
- Undo the 3 pump screws (1, fig. 66).

- Pull pump forward to remove.
- Fit new 'O' rings (supplied with pump) to pump connections.
- Re-assemble in reverse order.

Note: The pump screws are of two sizes. The longer screws must be fitted into the two lower holes, the shorter screw must be fitted into the top hole.

- Carry out electrical checks (see section 5.1).




7.13 Replacement of automatic air release

- Turn off boiler as in section 7.1.1.
- Remove front casing as in section 7.1.3.
- Release CH water pressure and drain boiler as in section 7.1.2.
- Lower front control panel as in section 7.1.6.
- Unscrew cap (2, fig. 66) of auto air release and remove inner components.
- Replace with new inner components and reassemble in reverse order.
- Refill and repressurise the boiler (see section 5.3).

7.14 Replacement of automatic bypass

- Turn off boiler as in section 7.1.1.
- Remove front casing as in section 7.1.3.
- Release CH water pressure and drain boiler as in section 7.1.2.
- Lower front control panel as in section 7.1.6.
- Remove spring clip (1, fig. 64).
- Disconnect wires from overheat thermostat (2, fig. 64).
- Remove temperature gauge phial from primary flow pipe.
- Undo unions (3, fig. 64). Remove bypass/connecting pipe.
- Undo union (1, fig. 67) to remove bypass (2, fig. 67).
- Reassemble in reverse order using sealing washers supplied.
- Refill and repressurise the boiler (see section 5.3).




7.15 Replacement of pressure and temperature gauge

- Turn off boiler as in section 7.1.1.
- Remove front casing as in section 7.1.3.
- Release CH water pressure and drain boiler as in section 7.1.2.
- Lower front control panel as in section 7.1.6.
- Undo union (4, fig 66) to release pressure gauge tube.
- Remove temperature gauge phial from pocket on primary flow pipe.
- Press spring clips on side of gauge to remove from front panel.
- Replace in reverse order.
- Refill and repressurise the boiler (see section 5.3).

7.16 Replacement of differential pressure switch

- Turn off boiler as in section 7.1.1.
- Remove front casing as in section 7.1.3.
- Release CH water pressure and drain boiler as in section 7.1.2.
- Lower front control panel as in section 7.1.6.
- Remove clip at rear of switch by pulling it to the left.
- Disconnect wires from switch (1, fig. 68).
- Pull pressure differential switch forward to remove.
- Reassemble in reverse order.
- Carry out electrical checks (see section 5.1).
- Refill and repressurise the boiler (see section 5.3).



7.17 Removal of printed circuit boards (PCBs)

Before commencing work on PCB replacements carry out the following:-
Diagnose that the boards require changing using the fault finding guide (see section 8: Fault finding).

- Turn off the boiler as in section 7.1.1.
- Remove front casing as in section 7.1.3.
- Lower front control panel as in section 7.1.6.
- Disconnect ignition leads from the rear of control box.
- Remove back of control box by undoing the 3 screws (1 and 2, fig. 63).

7.17.1 Replacement of switch and control boards

- Disconnect external wiring from boiler terminal strip.
- Unplug ribbon cable from control board (2, fig. 69).
- Unplug all leads from the both boards (1, fig. 69).
- Pull off switchboard board support.
- Pull switchboard carefully out of control box.
- Push four spring retaining clips (5, fig. 70) out, and gently lift control board out of control box.
- Reassemble in reverse order.

Note: When refitting the control board, ensure that the user control spindles (3, fig. 69) are aligned with the potentiometer and control switch holes (5, fig. 69) and that the locating rib of the potentiometer/switch correctly engages in the groove of the control knob spindle. Also ensure that when refitting the main switchboard the on/off control knob spindle (3, fig. 69) engages correctly into the on/off switch (5, fig. 69) mounted on the board.

- Carry out electrical checks (see section 5.1)




fig. 69

GW 615/1





fig. 70


GW 774/1

Check electrical supply and appliance fuses




Note 1
 For test purposes, disconnect external controls from terminals 3 - 4 and replace with a bridge between these terminals. If appliance then operates, the fault is with the external controls.


Check main on/off control, overheat thermostat and anti-surge fuse




Check Central Heating control and external controls




Check operation of pump




Check fan/flue gas system




Check operation of differential pressure switch



Check ignition system and gas section



Check operation of burner and modulation



9 Electrical diagrams

9.1 Functional Flow diagram: THERMOcompact VU 142/1 E, 182/1 E, 242/1 E, 282/1 E




fig. 73

GW 651/1_VC

9.2 Wiring diagram: THERMOcompact VU 142/1 E, 182/1 E, 242/1 E, 282/1 E




fig. 74

9.3 Schematic appliance circuit diagram: VU 142/1 E, 182/1 E, 242/1 E, 282/1 E








fig. 75

10. Short parts list

| Key No. | Description | Part No. | GC No. |
|---------|--|----------|--------|
| 01 | Fan | 19 0162 | |
| 02 | Air pressure switch | 05 0557 | |
| 03 | Main heat exchanger VU 142/1, 182/1 | 06 5009 | |
| 04 | Main heat exchanger VU 242/1 | 06 4951 | |
| 05 | Main heat exchanger VU 282/1 | 06 4952 | |
| 06 | Burner VU 142/1, 182/1 | 04 1981 | |
| 07 | Burner VU 242/1 | 04 1960 | |
| 08 | Burner VU 282/1 | 04 1961 | |
| 09 | Ignition electrode | 09 0562 | |
| 10 | Flame sensing electrode | 09 0563 | |
| 11 | HT lead (ignition electrode) | 09 1534 | |
| 12 | Expansion vessel VU 142/1 | 18 1045 | |
| | VU 182/1, 242/1, 283/1 | 18 1022 | |
| 13 | Pump | 16 1111 | |
| 14 | Gas valve (natural gas) | 05 3369 | |
| 15 | Modulating regulator (natural gas) | 17 0376 | |
| 16 | Switch and Control board | 13 0438 | |
| 17 | Main transformer | 28 7442 | |
| 18 | NTC temperature sensor | 25 2805 | |
| 19 | Temperature and pressure gauge | 10 1558 | |



1. Introduction

Note: This boiler must be installed and serviced by a competent person in accordance with the Gas Safety (Installation and Use) Regulations 1994. In the UK 'CORGI' Registered Installers undertake the work to a safe and satisfactory standard.

The THERMOcompact is a fully automatic, wall mounted, room sealed system boiler for central heating and domestic hot water (where a separate indirect hot water storage cylinder is also incorporated in the system).

The boiler has been designed for use with a sealed central heating system, and comes fully tested and assembled with a built-in circulating pump, bypass and expansion vessel.



THERMOcompact boilers carry 'CE' Mark. This demonstrates that the boilers fulfill the essential requirements of the Gas Appliance Directive (90/396/EEC) and the Gas Appliance (Safety) Regulations 1992.

The 'CE' Mark also demonstrates that the boilers comply with the requirements of the Electromagnetic Compatibility Directive (Directive 89/336/EEC), the Low Voltage Directive (73/23/EEC), the Boiler Efficiency Directive (92/42/EEC) and the Boiler (Efficiency) Regulations 1993.

The THERMOcompact meets the requirements of 'The Boiler (Efficiency) Regulations 1993 and therefore is deemed to meet the requirements of Directive 92/42/EEC on the efficiency requirements for new hot-water boilers fired with liquid or gaseous fuels.

The boiler is easily sited on any internal wall and can be installed with either a horizontal or vertical RSF (Room Sealed Fan assisted) flue. Flue extensions and additional bends and elbows are available for increased siting flexibility. (The boiler is not suitable for external installation).

If desired an inhibitor may be used in the system. Guidance on the use of inhibitors is contained in these instructions.

Natural Gas and LPG versions of the boiler are available.

The THERMOcompact has built-in diagnostic indicator lights which illuminate in sequence, giving information on the boiler status when operating and performance of key components to aid in commissioning and fault finding.

The data badge is fitted on the bottom of the combustion chamber.

See text of General Requirements for Installation Requirements or notes.

11. Supplementary information for THERMOcompact

VU 142/1 EB
 VU 182/1 EB
 VU 242/1 EB
 VU 282/1 EB

L.P.G. Appliances:

The appliance delivered is designed for use with LPG.
 Please read the instructions for installation therefore as follows:

Related documents to be supplemented by:

BS 5482: CP for domestic butane and propane gas burning installations

Part 1: Installations in permanent dwellings

Inlet pressure: Propane
 37 mbar (14.6 in W.G.)

Technical Data

| Type | VU 142/1 E B | VU 182/1 E B | VU 242/1 E B | VU 282/1 E B | |
|---|--------------------|--------------------|-------------------|---------------------|-------------------|
| Main burner jet size | 12 x 7/075 | 12 x 7/075 | 16 x 7/075 | 18 x 7/075 | number x mark. |
| Burner setting pressure | 17.1 (6.7) Propane | 23.9 (9.4) Propane | 25.1 (9.9) Propan | 26.6 (10.5) Propane | mbar (in W.G.) |
| Restrictor | 2 * 203 | 2 * 300 | 2 * 350 | 2 * 375 | marking |
| Delivered gas Propane Gross C.V. (s.t.) | G 31 95.65 | | | | MJ/m ² |
| Gas consumption (s.t.) | 0.63 | 0.81 | 1.08 | 1.25 | m ³ /h |

83 30 51 GB/IE



Head Office
Vaillant Ltd., Vaillant House,
Medway City Estate, Trident Close,
Rochester, Kent ME2 4EZ

Sales
Service Solutions
Technical Advice
Training

01634 292310
0870 6060 777
01634 292392
01634 292370

0698 V
Printed in Germany - Imprimé en Allemagne
Printed on 100 % recycled paper
Subject to alteration
We do not accept liability for damage arising as
a result of the non-observance of these instructions

VAILLANT SPARE PART CATALOGUE

Wall-hung heating boilers

THERMOcompact, COMBIcompact

VC 110,180,240 T,XT, VCW 240,280 T,XT

(conventional flue)



VC-VCW 221 T

(balanced flue)

VC 112,142,182,242,282 E





VCW 242,282 E

(room-sealed fan-assisted)



8025 39 GB 09/96


View of appliances




Content

| | Page |
|--|-------------|
| View of appliances | 1 - 2 |
| General view sheets | 3 - 8 |
| Main component 01 Water valve, Servo control valve, Hydraulically controlled diverter valve, Flow switch | 9 - 19 |
| Main component 04 Burner, Pilotburner | 21 - 33 |
| Main component 05 Gas section | 35 - 39 |
| Main component 06 Heat exchanger | 41 - 51 |
| Main component 07 Casing parts, Air/Flue gas duct assembly, Wallcase | 53 - 69 |
| Main component 08 Connection parts, Connection piping, Acc.-connection parts | 71 - 87 |
| Main component 13 Control box, Flue sensor | 89 - 99 |
| Main component 16 Pump | 101 - 103 |
| Main component 18 Expansion vessel | 105 - 109 |

View of appliances



General view sheets



VC 110 T, XT

Page

4

VC 112,142 E

5

VC 180,240 T, VCW 240,280 T, XT

6


VC-VCW 221 T

7


VC 182,242,282 E, VCW 242,282 E

8


General view sheets VC 110 T, XT




General view sheets VC 112,142 E




General view sheets VC 180,240 T, VCW 240,280 T, XT




General view sheets VC-VCW 221 T



General view sheets VC 182,242,282 E, VCW 242,282 E



Main component 01



Water valve, Servo control valve (to 04/95)
VCW 221, 240,280 T, 242,282 E
Water valve, Servo control valve (from 05/95)
VCW 221, 240,280 T, 242,282 E (CE marked)
Hydraulically controlled diverter valve
VCW 221, 240,280 T, 242,282 E
Flow switch
VC 110,180,221,240 T

Page


10 - 13

14 - 15

16 - 17

18 - 19


**Main component 01 Water valve, Servo control valve (to 04/95)
VCW 221, 240,280 T, 242,282 E**



Main component 01 Water valve, Servo control valve (to 04/95) VCW 221, 240,280 T, 242,282 E

| Pict. No. | Article-No. | Part | Indic. | Type, Remarks |
|-----------|-------------|--------------------------|--------|---|
| 1a | - | water valve, cpl. | | A VCW 221,240,280 T } VCW 242 E } see execution from 05/95 page 15 B VCW 280 T, 282 E } |
| 1b | 01-1156 | water valve, cpl. | | VCW 242 E (supplied with parts 2-7,14,15,21-27) |
| 2 | 01-3014 | top section | | supplied with parts 3,4 |
| 3 | 98-1506 | packingring | | |
| 4 | 01-2156 | stuffing box | | green inset |
| 5 | 98-1506 | packingring | | |
| 6 | 01-0050 | screw | | |
| 7 | 01-0003 | diaphragm screw | | |
| 8 | 10-4263 | spring | | |
| 9 | 01-0007 | diaphragm disc | | |
| 10 | 01-0312 | diaphragm | | |
| 11 | 01-2944 | water quantity regulator | | } only for water valves with distinctive mark " + " upon underside of part (see inset diagram) |
| 12 | 10-4267 | spring | | |
| 13 | 01-0020 | venturi | ø 3,32 | for type A |
| | 01-0021 | venturi | ø 3,53 | for type B |
| 14 | 01-2629 | overpressure valve | | |
| 15 | 01-0053 | water filter | | |
| 16 | 01-2533 | temperature selector | | for type A } for type B } supplied with parts 17,18 |
| | 01-2534 | temperature selector | | |
| 17 | 98-0305 | packingring | | |
| 18 | 98-0149 | o-ring | | |
| 19 | 12-5117 | handle | | |
| 20 | 10-5744 | screw | | |
| 21 | 98-1511 | packingring | | |
| 22 | 98-1755 | packingring | | |
| 23 | 01-0009 | spring | | |
| 24 | 19-1367 | disc | | |
| 25 | 01-0426 | diaphragm disc | | |
| 26 | 01-0318 | diaphragm | | |
| 27 | 08-8617 | fastening set | | |
| 28 | 01-2938 | water quantity regulator | | only for type 1b |


**Main component 01 Water valve, Servo control valve (to 04/95)
VCW 221, 240,280 T, 242,282 E**



**Main component 01 Water valve, Servo control valve (to 04/95)
VCW 221, 240,280 T, 242,282 E**

| Pict. No. | Article-No. | Part | Indic. | Type, Remarks |
|-----------|-------------|--------------------------|--------|---|
| 31 | 01-2646 | servo control valve | | supplied with parts 32-42 |
| 32 | 01-0727 | spindle | | |
| 33 | - | | | single delivery not possible, with spare part 01-2646 |
| 34 | 12-6223 | micro-switch | | |
| 35 | 15-0014 | nut | | |
| 36 | 15-0008 | screw | | |
| 37 | 28-0715 | disc | | |
| 38 | 28-4406 | spring | | |
| 39-40 | 21-3515 | lever | | |
| 41 | 19-1420 | disc | | |
| 42 | 11-8947 | screw | | |
| 43 | 15-4132 | bracket | | |
| 44 | 07-8407 | clip | | |
| 45 | - | connection piping | | see main component 08 |
| 46 | 98-2490 | packingring | | |
| 47 | 23-5727 | screw | | |
| 48 | 10-5716 | screw | | |
| 49 | 20-2622 | screw | | |
| 50 | 09-0034 | safety disc | | |
| 51 | 08-6462 | support | | with nylon bush (not available as spare part) |
| 52 | 01-2947 | water quantity regulator | | |
| 53 | 01-0081 | spring | | |

**Main component 01 Water valve, Servo control valve (from 05/95)
VCW 221, 240,280 T, 242,282 E**




02 - 01 - 006

**Main component 01 Water valve, Servo control valve (from 05/95)
VCW 221, 240,280 T, 242,282 E**

| Pict. No. | Article-No. | Part | Indic. | Type, Remarks |
|-----------|--------------------|-------------------------------------|--------|--|
| 1 | 01-1267 01-1251 | water valve water valve | | 221,240 T,242 E (with parts 2-9,11-14,16-22) 280 T,282 E (with parts 2-9,11-14,16-22) |
| 2 | 01-3056 | upper part | | |
| 3 | 01-0359 | diaphragm set | | with part 5 (5 x pieces) |
| 4 | - | not necessary for british execution | | |
| 5 | 11-8959 | screw | | |
| 6 | 01-2553 | temperature selector | | 221,240,242 |
| | 01-2554 | temperature selector | | 280,282 |
| 7 | 98-2497 | packingring | | |
| 8 | 12-5117 | handle | | |
| 9 | 10-5744 | screw | | |
| 10 | - | not necessary for british execution | | |
| 11 | 10-9918 | plug | | |
| 12 | 98-2484 | packingring | | |
| 13 | 01-2954 | water quantity regulator | | |
| 14 | 98-0287 | packingring | | |
| 15 | - | not necessary for british execution | | |
| 16 | 98-1506 | packingring | | |
| 17 | 01-2629 | overpressure valve | | |
| 18 | 01-0050 | screw | | |
| 19 | 01-2854 | venturi | ø 2,10 | 221,240,242 |
| | 01-2819 | venturi | ø 2,80 | 280,282 |
| 20 | 12-8516 | water filter | | |
| 21 | 98-0197 | packingring | | |
| 22 | 98-0186 | packingring | | |


**Main component 01 Hydraulically controlled diverter valve
VCW 221, 240,280 T, 242,282 E**



Main component 01 Hydraulically controlled diverter valve VCW 221, 240,280 T, 242,282 E

| Pict. No. | Article-No. | Part | Indic. | Type, Remarks |
|-----------|-------------|------------------------|--------|---|
| 1 | 01-2684 | diverter valve | | supplied with parts 2-15,17 |
| 2 | 01-0003 | diaphragm screw | | |
| 3 | 10-4244 | spring | | |
| 4 | 02-0630 | valve disc | | |
| 5 | 98-2488 | packingring | | |
| 6 | 98-1518 | packingring | | |
| 7 | 01-2140 | stuffing box | | |
| 8 | 01-0457 | diaphragm disc | | |
| 9 | 01-0337 | diaphragm | | |
| 10 | 01-0421 | diaphragm disc | | |
| 11 | 01-2141 | stuffing box | | |
| 12 | 12-6233 | micro-switch | | |
| 13 | 10-5760 | screw | | |
| 14 | 20-5521 | cap | | |
| 15 | 98-1511 | packingring | | |
| 16-16a | 15-5614 | screw | | |
| 17 | 98-1898 | packingring | | |
| 18 | 08-4245 | flow switch connection | | |
| 19 | 08-8940 | flow switch connection | | |
| 20 | 13-6313 | nipple | | |
| 21 | - | connection piping | | see main component 08 |
| 22 | - | bracket | | single delivery not possible, with spare part 01-2684 |
| 23 | - | microswitch bracket | | single delivery not possible, with spare part 12-6233 |


Main component 01 Flow switch
VC 110,180,221,240 T



**Main component 01 Flow switch
VC 110,180,221,240 T**


| Pict. No. | Article-No. | Part | Indic. | Type, Remarks |
|-----------|-------------|--------------|--------|-------------------------------|
| 1 | - | support | | not available as a spare part |
| 2 | 12-6235 | micro-switch | | |
| 3 | 14-0012 | screw | | |
| 4 | 28-0715 | disc | | |
| 5 | 20-4049 | cap | | |
| 6 | 15-1027 | flow switch | | |
| 7 | 13-0005 | screw | | |
| 8 | 15-4133 | bow | | |

Main component 04



| | Page |
|--|-------------|
| Burner, Pilotburner VC 110 T H,B | 22 - 23 |
| Burner VC 112 E H,B | 24 - 25 |
| Burner VC 142 E H,B | 26 - 27 |
| Burner, Pilotburner VC 180,240 T, VCW 240,280 T H,B | 28 - 29 |
| Burner, Pilotburner VC-VCW 221 T H,B | 30 - 31 |
| Burner VC 182,242,282 E, VCW 242,282 E H,B | 32 - 33 |


**Main component 04 Burner, Pilotburner
VC 110T H,B**



Main component 04 Burner, Pilotburner VC 110 T H,B

| Pict. No. | Article-No. | Part | Indic. | Type, Remarks |
|-----------|-------------|----------------------|--------|-----------------------------|
| | | | | H = Natural gas, B = LP-gas |
| 1 | 18-3971 | distributor tube | | |
| 2 | 24-7150 | burner nozzle | ø 1,50 | H |
| | 24-7080 | burner nozzle | ø 0,80 | B |
| 3 | 04-0467 | burner chamber group | | |
| 4 | 13-3936 | screw | | |
| 5 | 23-5728 | screw | | |
| 6 | - | - | | see main component 08 |
| 7 | 04-9601 | throttle jet | ø 3,05 | B |
| 8 | 98-2481 | packingring | | B |
| 9 | 98-2495 | packingring | | |
| 10 | 10-5758 | screw | | |
| 11 | 23-5728 | screw | | |
| 12 | 04-2959 | pilot burner support | | supplied with parts 13,14 |
| 13 | 09-0658 | ignition electrode | | |
| 14 | 13-9201 | screw | | |
| 15 | 04-2864 | pilot burner nozzle | ø 0,30 | H |
| | 04-2874 | pilot burner nozzle | ø 0,18 | B |
| 16 | 04-3936 | pilot burner tube | | |
| 17 | 17-1169 | thermo-couple | | |

Main component 04 Burner
VC 112 E H,B




02 - 04 - 015

Main component 04 Burner VC 112 E H,B

| Pict. No. | Article-No. | Part | Indic. | Type, Remarks |
|-----------|--|------------------------|--------|-----------------------------|
| | | | | H = Natural gas, B = LP-gas |
| 1 | 18-3974 | distributor tube | | supplied with part 28 |
| 2 | 24-7140 | burner nozzle | Ø 1,40 | H |
| | 24-7078 | burner nozzle | Ø 0,78 | B |
| 3 | 04-0467 | burner chamber group | | |
| 4 | 09-0649 | monitoring electrode | | right |
| 5 - | ignition electrode replaced pict.-no. 25-27, 09-0673 | | | |
| 6 | 09-1513 | ignition wire | | |
| 7 | 13-9203 | screw | | |
| 8 | 09-0034 | safety disc | | |
| 9 | 13-3936 | screw | | |
| 10 | 98-2481 | packingring | | B |
| 11 | 04-9601 | throttle jet | Ø 3,05 | B |
| 12 | 98-2495 | packingring | | |
| 13 | - | connection parts | | see main component 08 |
| 14 | 23-5728 | screw | | |
| 15 | 10-5758 | screw | | |
| 16 | 23-5727 | screw | | |
| 17 | 08-8932 | flow switch connection | | |
| 18 | 04-0364 | nut | | |
| 19 | 98-1805 | packingring | | |
| 20 | 08-1063 | connection | | |
| 21 | 08-0369 | hose | 250 mm | |
| 22 | 13-3504 | nipple | | |
| 23 | 13-3505 | nipple | | |
| 24 | 08-8936 | flow switch connection | | |
| 25-27 | 09-0673 | ignition electrode | | left (supplied with part 6) |
| 28 | 08-5859 | support | | |
| 29 | 25-5928 | cable tree | | |


Main component 04 Burner
VC 142 E H,B



Main component 04 Burner VC 142 E H,B

| Pict. No. | Article-No. | Part | Indic. | Type, Remarks |
|-----------|-------------|------------------------|--------|-----------------------------|
| | | | | H = Natural gas, B = LP-gas |
| 1 | 18-3905 | distributor tube | | |
| 2 | 24-7140 | burner nozzle | Ø 1,40 | H |
| | 24-7078 | burner nozzle | Ø 0,78 | B |
| 3 | 04-1920 | burner chamber group | | |
| 4 | 09-0649 | monitoring electrode | | right |
| 5 | 06-0018 | screw | | |
| 6 | 09-0034 | safety disc | | |
| 7 | 09-0673 | ignition electrode | | left (supplied with part 6) |
| 8 | 09-1513 | ignition wire | | |
| 9 | 13-3936 | screw | | |
| 10 | 98-2495 | packingring | | |
| 12 | 08-5859 | support | | |
| 13 | 10-5758 | screw | | |
| 14 | 23-5727 | screw | | |
| 15 | 08-8946 | flow switch connection | | |
| 16 | 04-0364 | nut | | |
| 17 | 98-1805 | packingring | | |
| 18 | 08-1063 | connection | | |
| 19 | 08-0369 | hose | | |
| 20 | 13-3504 | nipple | | |
| 21 | 13-3505 | nipple | | |
| 22 | 08-8947 | flow switch connection | | |
| 23 | 98-2481 | packingring | | B |
| 24 | 04-9608 | throttle jet | Ø 3,25 | B |
| 31 | 08-4945 | connection piece | | |
| 32 | 25-5928 | cable tree | | |


Main component 04 Burner, Pilotburner
VC 180,240 T, VCW 240,280 T H,B



Main component 04 Burner, Pilotburner VC 180,240 T, VCW 240,280 T H,B

| Pict. No. | Article-No. | Part | Indic. | Type, Remarks |
|-----------|-------------|----------------------|------------|--|
| | | | | S = town gas, H = Natural gas, B = LP-gas |
| 1 | 18-3968 | distributor tube | | 180 |
| | 18-3969 | distributor tube | | 240,280 |
| 2 | 24-7260 | burner nozzle | Ø 2,60 | S |
| | 24-7150 | burner nozzle | Ø 1,50 | H |
| | 24-7080 | burner nozzle | Ø 0,80 | B |
| 3 | 04-0467 | burner chamber group | | 180 |
| | 04-0468 | burner chamber group | | 240,280 |
| 6 | 06-0018 | screw | | |
| 8 | 04-2951 | pilot burner support | | supplied with parts 6,11 |
| 11 | 09-0643 | ignition electrode | | |
| 12 | 04-2876 | pilot burner nozzle | Ø 0,45 | S |
| | 04-2864 | pilot burner nozzle | Ø 0,30 | H |
| | 04-2874 | pilot burner nozzle | Ø 0,18 | B |
| 13 | 17-1165 | thermo-couple | | |
| 14 | 04-3931 | pilot burner tube | | |
| 17 | 13-3936 | screw | | |
| 18 | 08-4957 | connection piece | | |
| 19 | 98-2495 | packingring | | |
| 20 | 98-2481 | packingring | | B |
| 21 | 04-9604 | throttle jet | Ø 3,40 | 180 B |
| | 04-9603 | throttle jet | Ø 4,00 | 240 B |
| | 04-9612 | throttle jet | 3 x Ø 3,50 | 280 B |
| 22 | 98-1512 | packingring | | |
| 23 | 23-5727 | screw | | |
| 24 | 10-5758 | screw | | |
| 25 | 23-5728 | screw | | |
| 26 | 09-1060 | piezo ignition | | lead attached to piezo ignition unit, not available seperatley |


Main component 04 Burner, Pilotburner VC-VCW 221 T H,B



Main component 04 Burner, Pilotburner VC-VCW 221 T H,B

| Pict. No. | Article-No. | Part | Indic. | Type, Remarks |
|-------------------|-------------|--|--------|---|
| | | | | S = town gas, H = Natural gas, B = LP-gas |
| 1 | 18-3973 | distributor tube | | |
| 2 | 24-7130 | burner nozzle | Ø 1,30 | H |
| | 24-7078 | burner nozzle | Ø 0,78 | B |
| 3 | 04-0468 | burner chamber group | | |
| 4 | 04-2968 | pilot burner support | | supplied with parts 5,6 |
| 5 | 09-0658 | ignition electrode | | |
| 6 | 13-9201 | screw | | |
| 7 | 04-2876 | pilot burner nozzle | Ø 0,45 | S |
| | 04-2864 | pilot burner nozzle | Ø 0,30 | H |
| | 04-2874 | pilot burner nozzle | Ø 0,18 | B |
| 8 | 04-3939 | pilot burner tube | | |
| 9 - thermo-couple | | old execution, see pict.-no. 35 (new) replaced | | 17-1181 |
| 10 | 13-3936 | screw | | |
| 11 | 08-4944 | connection piece | | |
| 12 | 98-2495 | packingring | | |
| 13 | 98-2481 | packingring | | B |
| 14 | 04-9607 | throttle jet | Ø 3,70 | B |
| 15 | 98-1512 | packingring | | |
| 16 | 10-5758 | screw | | |
| 17 | 23-5727 | screw | | |
| 18 | 23-5728 | screw | | |
| 19 | 98-1805 | packingring | | |
| 20 | 04-0364 | nut | | |
| 21 | 13-3504 | nipple | | |
| 22 | 13-3505 | nipple | | |
| 23 | 08-8949 | flow switch connection | | |
| 24 | 08-8930 | flow switch connection | | |
| 25 | 08-3891 | tube | | |
| 26 | 98-2499 | packingring | | |
| 27 | 08-1063 | connection | | |
| 28 | 98-0202 | packingring | | |
| 29 | 11-4848 | nut | | |
| 30 | 08-0369 | hose | 250 mm | diaphragm pump |
| 31 | 98-0765 | packingring | | |
| 32 | 07-0881 | cover plate | | supplied with parts 33,34 |
| 33 | 06-0021 | disc | | |
| 34 | 23-5715 | screw | | |
| 35 | 17-1181 | thermo-couple | | |

Main component 04 Burner
VC 182,242,282 E, VCW 242,282 E H,B




Main component 04 Burner

VC 182,242,282 E, VCW 242,282 E H,B

| Pict. No. | Article-No. | Part | Indic. | Type, Remarks |
|-----------|-------------------------------|---|-------------------------------|---|
| | | | | S = town gas, H = Natural gas, B = LP-gas |
| 1 | 18-3972 18-3973 | distributor tube distributor tube | | 182 242,282 |
| 2 | 24-7260 24-7140 24-7078 | burner nozzle burner nozzle burner nozzle | Ø 2,60 Ø 1,40 Ø 0,78 | S H B |
| 3 | 04-0467 04-0468 | burner chamber group burner chamber group | | 182 242,282 |
| 4 | 09-0649 | monitoring electrode | | right |
| 6 | 13-9203 | screw | | |
| 7 | 09-0034 | safety disc | | |
| 8 | 13-3936 | screw | | |
| 9 | 08-4944 | connection piece | | supplied with part 10 |
| 10 | 98-2495 | packingring | | |
| 11 | 98-2481 | packingring | | B |
| 12 | 04-9604 04-9603 04-9610 | throttle jet throttle jet throttle jet | Ø 3,40 Ø 4,00 2x Ø 3,10 | 182 B 242 B 282 B |
| 13 | 98-1512 | packingring | | |
| 14 | 23-5727 | screw | | |
| 15 | 10-5758 | screw | | |
| 16 | 23-5728 | screw | | |
| 17 | 98-1805 | packingring | | |
| 18 | 04-0364 | nut | | |
| 19 | 13-3504 | nipple | | |
| 20 | 13-3505 | nipple | | |
| 21 | 08-8949 | flow switch connection | | |
| 22 | 07-0881 | cover plate | | |
| 23 | 06-0021 | disc | | |
| 24 | 23-5715 | screw | | |
| 25 | 08-8930 | flow switch connection | | |
| 26 | 09-1513 | ignition wire | | |
| 27 | 08-3891 | tube | | |
| 28 | 98-2499 | packingring | | |
| 29 | 08-1063 | connection | | |
| 30 | 98-0202 | packingring | | |
| 31 | 11-4848 | nut | | |
| 32 | 08-0369 | hose | 250 mm | |
| 33 | 98-0765 | packingring | | |
| 34-36 | 09-0673 | ignition electrode | | left (supplied with part 26) |
| 37 | 25-5928 25-5929 | cable tree cable tree | | VC... VCW... |

Main component 05




Gas section
VC 110,180,221,240 T, VCW 221,240,280 T H, B
Gas section
VC 112,142,182,242,282 E, VCW 242,282 E H, B

Page

36 - 37

38 - 39


Main component 05 Gas section
VC 110,180,221,240 T, VCW 221,240,280 T H, B



Main component 05 Gas section
VC 110,180,221,240 T, VCW 221,240,280 T H, B

| Pict. No. | Article-No. | Part | Indic. | Type, Remarks |
|-----------|-------------------------------|---|--------------|---|
| | | | | S = town gas, H = Natural gas, B = LP-gas |
| 2 | 05-3073 05-3076 | gas section gas section | | S,H } B } supplied with parts 3,4,13,28,30-40 |
| 3 | 98-0831 | packingring | | |
| 4 | 05-0224 05-0167 | operator operator | | S,H } B } supplied with parts 3,6 |
| 5 | 21-9235 21-9233 21-9232 | operating jet operating jet operating jet | 19 M 16 M | 110,180 H S, 180,221,240 H B |
| 6 | 98-1504 | packingring | | |
| 7 | 21-8011 08-4128 | flow switch connection hose connection | | 110 180-280 |
| 8 | 08-0357 | hose | 145 mm | |
| 9 | 13-3702 | screw | | |
| 10 | 10-5782 | screw | | |
| 11 | 21-8013 08-4127 08-8930 | flow switch connection hose connection flow switch connection | | 110 180,240,280 221 |
| 12 | 08-0358 | hose | 60 mm | 110,180,240,280 |
| 13 | 49-2147 | screw | | |
| 28 | 20-4038 | cap | | |
| 29 | 07-1472 | push button | | |
| 30 | 12-6234 | micro-switch | | |
| 31 | 06-0018 | screw | | |
| 32 | 49-2112 | disc | | |
| 33 | 17-0295 | magneto | | |
| 34 | 98-2472 | packingring | | |
| 35 | 98-0842 | packingring | | |
| 36 | 19-5031 | magneto housing | | |
| 37 | 10-5758 | screw | | |
| 38 | 11-1459 | disc | | |
| 39 | 17-0025 | locking plate | | |
| 40 | 04-0364 | nut | | |
| 41 | 08-9526 | connection line | | no longer required on VC-VCW 221 only, use part 17-1181 |


Main component 05 Gas section
VC 112,142,182,242,282 E, VCW 242,282 E H, B



Main component 05 Gas section
VC 112,142,182,242,282 E, VCW 242,282 E H, B


| Pict. No. | Article-No. | Part | Indic. | Type, Remarks |
|-----------|-------------------------------|--|-----------------|--|
| | | | | S = town gas, H = Natural gas, B = LP-gas |
| 1 | 05-3255 05-3079 | gas section gas section | | S,H } B } supplied with parts 2,4,6,10,13-21 |
| 2 | 05-0224 | operator | | S,H } B } supplied with parts 4,6 |
| 3 | 05-0167 05-0164 | operator operator | | H (with part load device) |
| 4 | 98-0831 | packingring | | |
| 5 | 21-9233 21-9235 21-9232 | operating jet operating jet operating jet | 16 M 19 M | S H B |
| 6 | 98-0224 | packingring | | |
| 7 | 21-8011 08-4128 | flow switch connection hose connection | | 112,142 182,242,282 |
| 8 | 08-0357 | hose | 145 mm | |
| 9 | 13-3702 | screw | | |
| 10 | 10-5782 | screw | | |
| 11 | 08-8947 08-8930 | flow switch connection flow switch connection | | 112,142 182,242,282 |
| 12 | 08-0358 08-0369 | hose hose | 60 mm 255 mm | |
| 13 | 11-8948 | screw | | |
| 14 | 15-1017 | pressure diff. switch | | |
| 15-16 | - | - | | single delievery not possible, with part 15-1017 |
| 17 | 01-2156 | stuffing box | | |
| 18 | 98-0223 | packingring | | |
| 19 | 11-8947 | screw | | |
| 20 | - | diaphragm disc | | single delievery not possible, with part 15-1017 |
| 21 | 02-0220 | diaphragm | | |
| 22-27 | - | connection | | see main component 08 |
| 28 | 98-2490 | packingring | | |
| 29 | 15-4133 | bow | | |
| 40 | 10-5758 | screw | | |

Main component 06



| | Page |
|---|-------------|
| Heat exchanger VC 110,180,240 T, VCW 240,280 T | 42 - 43 |
| Heat exchanger VC 112,182,242,282 E, VCW 242,282 E | 44 - 45 |
| Heat exchanger VC 142 | 46 - 47 |
| Heat exchanger VC-VCW 221 | 48 - 49 |
| Heat exchanger (DHW) VCW 180-282 E | 50 - 51 |

Main component 06 Heat exchanger
VC 110,180,240 T, VCW 240,280 T




02 - 06 - 011

Main component 06 Heat exchanger VC 110,180,240 T, VCW 240,280 T

| Pict. No. | Article-No. | Part | Indic. | Type, Remarks |
|-----------|--|--|--------|--|
| 1 | 06-1849 06-1835 06-1836 06-1872 | heat exchanger heat exchanger heat exchanger heat exchanger | | 110 } 180 } supplied with parts 2-4 240 } 280 } |
| 2 | 98-1511 | packingring | | supplied with part 4 |
| 3 | 17-7511 | de-aeration screw | | |
| 4 | 98-2459 | packingring | | |
| 5 | 10-1462 | temperature limiter | | |
| 6 | 13-3908 | screw | | |
| 7 | 11-8335 11-8463 11-8465 11-8467 | combustion chamber combustion chamber combustion chamber combustion chamber | | |
| 8-9 | - | single delivery not possible | | see pict.-nr. 7 |
| 10 | 08-8624 | screw | | |
| 11 | 07-9415 07-9416 07-9407 07-9405 | guide plate guide plate air duct air duct | | 110 right 110 left 180 240,280 |
| 12 | 08-4937 08-4936 08-4953 | connection piece connection piece connection piece | | 180 240 280 |
| 13 | 23-5727 | screw | | |
| 14 | - | connection | | see main component 08 |
| 15 | - | heat exchanger (DHW) | | replaced by, 06-5034 see page 50 + 51 |
| 16 | 98-1602 | packingring | | } VCW only |
| 17 | 98-1609 | packingring | | |
| 18 | 08-4939 | connection piece | | 110 |
| 19 | 08-9572 | connection line | | |
| 20 | 08-9571 | connection line | | |
| 21 | 15-3396 | guide plate | | only 280 |
| 22 | 16-1225 | inspection glass | | } only 110 |
| 23 | 13-1813 | frame for inspection glass | | |

Main component 06 Heat exchanger
VC 112,182,242,282 E, VCW 242,282 E




Main component 06 Heat exchanger

VC 112,182,242,282 E, VCW 242,282 E

| Pict. No. | Article-No. | Part | Indic. | Type, Remarks |
|-----------|--|--|--------|--|
| 1 | 06-1849 06-1835 06-1836 06-1872 | heat exchanger heat exchanger heat exchanger heat exchanger | | 112 } 182 } supplied with parts 2-4 242 } 282 } |
| 2 | - | packingring | | see main component 08 |
| 3 | 17-7511 | de-aeration screw | | supplied with part 4 |
| 4 | 98-2459 | packingring | | |
| 5 | 10-1384 10-1392 10-1391 | temperature limiter temperature limiter temperature limiter | | 112 182 242,282 |
| 6 | 08-4939 08-4942 08-4941 08-4959 | connection piece connection piece connection piece connection piece | | 112 182 242 282 |
| 7 | 11-8335 11-8464 11-8466 11-8468 | combustion chamber combustion chamber combustion chamber combustion chamber | | 112 } 182 } supplied with parts 8,9 242 } 282 } |
| 8-9 | - | single delivery not possible | | see pict.-nr. 7 |
| 10 | 08-8624 | screw | | 3,5 + 4,8 x 9,5 |
| 11 | 07-9415 07-9416 | guide plate guide plate | | right } left } only VC 112 |
| 12 | - | not necessary | | |
| 13 | 23-5727 | screw | | |
| 14 | - | connection tube | | see main component 08 |
| 15 | - heat exchanger (DHW) replaced , 06-4953 see page 50 + 51 | | | |
| 16 | 98-1602 | packingring | | } VCW only |
| 17 | 98-1609 | packingring | | |
| 18 | - | not necessary | | |


Main component 06 Heat exchanger VC 142



Main component 06 Heat exchanger VC 142

| Pict. No. | Article-No. | Part | Indic. | Type, Remarks |
|-----------|-------------|---------------------|--------|-----------------------|
| 1 | 06-1849 | heat exchanger | | supplied with part 2 |
| 2 | - | packingring | | see main component 08 |
| 3 | 10-1384 | temperature limiter | | |
| 4 | 08-4939 | connection piece | | |
| 5 | 11-8334 | combustion chamber | | |
| 6 | 15-3338 | guide plate | | |
| 7 | 07-9424 | guide plate | | |
| 8 | 07-9425 | guide plate | | |
| 9 | 08-8624 | screw | | |
| 10 | 23-5727 | screw | | |


Main component 06 Heat exchanger VC-VCW 221



Main component 06 Heat exchanger VC-VCW 221

| Pict. No. | Article-No. | Part | Indic. | Type, Remarks |
|-----------|-------------|----------------------|--------|---|
| 1 | 06-1891 | heat exchanger | | supplied with parts 2,3,8 supplied with part 3 |
| 2 | 17-7511 | de-aeration screw | | |
| 3 | 98-2459 | packingring | | |
| 4 | 10-1462 | temperature limiter | | supplied with part 8 |
| 5 | 13-3908 | screw | | |
| 6 | 08-9572 | connection line | | |
| 7 | 08-9571 | connection line | | |
| 8 | 98-1511 | packingring | | |
| 9 | 11-8328 | combustion chamber | | |
| 10 | 08-9134 | connection | | |
| 11 | - | connection tube | | |
| 12 | - | heat exchanger (DHW) | | replaced by, 06-5034 see page 50 + 51 |
| 13 | 98-1609 | packingring | | |
| 14 | 98-1602 | packingring | | |
| 15 | 23-5715 | screw | | } VCW only |
| 16 | 08-1316 | connecting tube | | |
| 17 | 08-9186 | connecting tube | | |

**Main component 06 Heat exchanger (DHW)
VCW 180-282 E**




02 - 06 - 009

Main component 06 Heat exchanger (DHW) VCW 180-282 E


| Pict. No. | Article-No. | Part | Indic. | Type, Remarks |
|-----------|--------------------|--|--------|--|
| 1 | 06-4946 06-5034 | heat exchanger (DHW) heat exchanger set | | supplied with parts 6,7 supplied with parts 2-7,9 replacement for the plastic DHW heat exchanger 06-1834 |
| 2 | 08-9298 | connecting tube | | |
| 3 | 08-9094 | connecting tube | | |
| 4 | 08-9299 | connecting tube | | |
| 5 | 08-9003 | cold water tube,cpl. | | |
| 6 | 98-0151 | packingring | | |
| 7 | 98-0012 | packingring | | |
| 8 | - | water valve | | see main component 01 |
| 9 | - | Hydraulically controlled diverter valve | | see main component 01 |

Main component 07



| | Page |
|---|-------------|
| Casing parts VC 110 T, 112 E | 54 - 55 |
| Casing parts VC 142 E | 56 - 57 |
| Casing parts VC 180,240 T, VCW 240,280 T | 58 - 59 |
| Casing parts VC 182,242,282 E, VCW 242,282 E | 60 - 61 |
| Casing parts VC-VCW 221 T | 62 - 63 |
| Air/Flue duct assembly VC 112,142,182,242,282 E, VCW 242,282 E | 64 - 65 |
| Wallcase VC-VCW 221 T | 66 - 67 |
| Vertical air/flue duct assembly VC 112,142,182,242,282 E, VCW 242,282 E (Acc.-no. 9293,9020,9056,9076,9077) | 68 - 69 |

Main component 07 Casing parts
VC 110T, 112 E




02 - 07 - 012

Main component 07 Casing parts VC 110 T, 112 E

| Pict. No. | Article-No. | Part | Indic. | Type, Remarks |
|-----------|-------------|----------------------------------|--------|---|
| 1 | 07-2914 | cowling | | |
| 2 | 07-5460 | covering plate | | |
| 3 | 07-1472 | push button | | 110 T |
| | 20-8672 | covering plate | | 112 E |
| 4 | 07-0046 | screw | | |
| 5 | 04-0186 | tension ring | | |
| 6 | 21-3365 | back panel | | } only for 110 T |
| 7 | 07-4945 | draft diverter | | |
| 8 | 23-5727 | screw | | |
| 9 | - | single delivery not possible | | |
| 10 | 98-0766 | packingring | | } only for 112 E |
| 11 | 98-0765 | packingring | | |
| 12 | 07-8257 | covering plate | | |
| 13 | 20-4063 | cap | | |
| 14 | 98-1746 | packingring | | |
| 15 | 16-1225 | inspection glass | | |
| 16 | 20-8719 | covering plate | | |
| 17 | 08-8624 | screw | | |
| 18 | 13-0005 | screw | | |
| 19 | 07-8272 | covering plate | | |
| | | supplied with parts 11,13-17 | | |
| 20 | 08-8214 | flue adaptor | | 110 T |
| | | Timer assembly, acc.-no. 2378053 | | |
| - | 2370101 | covering plate | | } black plastic spring clips are separate } not shown |
| - | 2370099 | time clock | | |
| - | 2370100 | wiring harness | | |


Main component 07 Casing parts VC 142 E



Main component 07 Casing parts VC 142 E

| Pict. No. | Article-No. | Part | Indic. | Type, Remarks |
|-----------|-------------|----------------------------------|--------|---|
| 1 | 07-2914 | cowling | | supplied with parts 3-5 |
| 2 | 07-5460 | covering plate | | |
| 3 | 20-8672 | covering plate | | |
| 4 | 07-0046 | screw | | |
| 5 | 04-0186 | tension ring | | |
| 6 | 07-8272 | covering plate | | supplied with parts 7-12 |
| 7 | 98-1746 | packingring | | |
| 8 | 16-1225 | inspection glass | | |
| 9 | 20-8719 | covering plate | | |
| 10 | 08-8624 | screw | | |
| 11 | 20-4063 | cap | | |
| 12 | 98-0765 | packingring | | |
| 13 | 98-0766 | packingring | | |
| 14 | 13-0005 | screw | | |
| | | Timer assembly, acc.-no. 2378053 | | |
| - | 2370101 | covering plate | | black plastic spring clips are separate } not shown |
| - | 2370099 | time clock | | |
| - | 2370100 | wiring harness | | |

Main component 07 Casing parts
VC 180,240 T, VCW 240,280 T




Main component 07 Casing parts

VC 180,240 T, VCW 240,280 T

| Pict. No. | Article-No. | Part | Indic. | Type, Remarks |
|-----------|-------------|----------------------------------|-----------|---|
| 1 | - | chassis | | not available as a spare part |
| 2 | 15-4220 | bow | | |
| 3 | 15-4227 | bow | | |
| 4 | 08-6322 | support | | |
| 5 | 23-5727 | screw | | |
| 6 | 07-0357 | nut | | |
| 7 | 98-0093 | packingring | | |
| 8 | 06-0020 | disc | | |
| 9 | 07-0350 | screw | | |
| 10 | 23-5737 | screw | | |
| 11 | 14-9627 | support | | 180 |
| | 14-9628 | support | | 240,280 |
| 12 | 21-3362 | back panel | | |
| 13 | 13-9203 | screw | | |
| 14 | 11-6477 | screw | | |
| 15 | 22-1723 | support | | |
| 16 | 12-6153 | spring | | |
| 17 | 07-4920 | draft diverter | | 180 |
| | 07-4921 | draft diverter | | 240 |
| | 07-4940 | draft diverter | | 280 |
| 18 | 07-5461 | covering plate | | |
| 19 | 13-3799 | screw | M 8 x 4 | knurled |
| | 23-5715 | screw | 4,8 x 9,5 | sheet metal (from 04/95) |
| 20 | 07-1472 | push button | | |
| 21 | 07-9920 | lateral panel | right | supplied with parts 9,22-27 |
| 22-27 | 08-8620 | fastening set | | supplied with part 28 |
| 28 | 07-0351 | screw | | |
| 29 | 07-9921 | lateral panel | left | |
| 30 | 29-4012 | top door | | 180,240 (supplied with parts 32-35) |
| | 29-4030 | top door | | 280 (supplied with parts 32-37) |
| 31 | 29-4013 | bottom door | | supplied with parts 32-35 |
| 32 | 17-0356 | door magnet | | only for 180,240 (slide on version from 04/95) |
| | 07-0355 | door magnet | | 280 (screwed type) |
| 33 | 15-8207 | nut | | |
| 34 | 23-5748 | screw | | |
| 35 | 12-4870 | bush | | |
| 36 | 21-3377 | back panel | | } only for 280 |
| 37 | 23-5748 | screw | | |
| 38 | 15-3375 | guide plate | | |
| 39 | 08-8215 | flue adaptor | | 180 |
| | 08-8216 | flue adaptor | | 240 |
| | 08-8214 | flue adaptor | | 280 |
| | | Timer assembly, acc.-no. 2378054 | | |
| - | 2370102 | covering plate | | } black plastic spring clips are separate } not shown |
| - | 2370099 | time clock | | |
| - | 2370100 | wiring harness | | |

Main component 07 Casing parts
VC 182,242,282 E, VCW 242,282 E




Main component 07 Casing parts

VC 182,242,282 E, VCW 242,282 E

| Pict. No. | Article-No. | Part | Indic. | Type, Remarks |
|-----------|-------------|----------------------------------|-----------|--|
| 1 | - | chassis | | not available as a spare part |
| 2 | 15-4227 | bow | | |
| 3 | 07-0357 | nut | | |
| 4 | 98-0093 | packingring | | |
| 5 | 06-0020 | disc | | |
| 6 | 07-0350 | screw | | |
| 7 | 23-5737 | screw | | |
| 8 | 14-9627 | support | | 182 |
| | 14-9628 | support | | 242,282 |
| 9 | 23-5727 | screw | | |
| 10 | 11-6477 | screw | | |
| 11 | 98-0766 | packingring | | |
| 12 | 98-0765 | packingring | | |
| 13 | 20-7267 | side panel | | |
| 14 | 23-5715 | screw | | |
| 15 | 07-8253 | front panel | | screwed type (supplied with parts 12,16-19,36) |
| | 07-8274 | front panel | | snapped type (supplied with parts 16-19) |
| 16 | 28-2249 | ring | | |
| 17 | 98-1746 | packingring | | |
| 18 | 16-1225 | inspection glass | | |
| 19 | 23-5748 | screw | | |
| 20 | 07-5461 | covering plate | | supplied with part 20-8672 |
| | 20-8672 | covering plate | | not shown |
| 21 | 13-3799 | screw | M 8 x 4 | knurled |
| | 23-5715 | screw | 4,8 x 9,5 | sheet metal (from 04/95) |
| 22 | 07-9920 | lateral panel | right | supplied with parts 23-28 |
| 23-28 | 08-8620 | fastening set | | supplied with part 29 |
| 29 | 07-0351 | screw | | |
| 30 | 07-9921 | lateral panel | left | |
| 31 | 29-4012 | top door | | } supplied with parts 19,33-35 |
| 32 | 29-4013 | bottom door | | |
| 33 | 15-8207 | nut | | |
| 34 | 17-0356 | door magnet | | slide on version from 04/95 |
| | 07-0355 | door magnet | | screwed type |
| 35 | 12-4870 | bush | | |
| 36 | 20-4063 | cap | | |
| | | Timer assembly, acc.-no. 2378054 | | VC 182,242 E, VCW 242 E |
| | | Timer assembly, acc.-no. 2378055 | | VC-VCW 282 E |
| - | 2370102 | covering plate | | VC 182,242 E, VCW 242 E |
| - | 2370103 | covering plate | | VC-VCW 282 E |
| - | 2370099 | time clock | | black plastic spring clips are separate |
| - | 2370100 | wiring harness | | } not shown |


**Main component 07 Casing parts
VC-VCW 221 T**



Main component 07 Casing parts VC-VCW 221 T

| Pict. No. | Article-No. | Part | Indic. | Type, Remarks |
|-----------|-------------|-------------------------|-----------|-------------------------------|
| 1 | - | chassis | | not available as a spare part |
| 2 | 20-8816 | support | | |
| 3 | 11-6462 | screw | | |
| 4 | 11-4848 | nut | | |
| 5 | 15-4227 | bow | | |
| 6 | 07-0350 | screw | | |
| 7 | 06-0020 | disc | | |
| 8 | 98-0093 | packingring | | |
| 9 | 07-0357 | nut | | |
| 10 | 23-5737 | screw | | |
| 11 | 14-9628 | support | | |
| 12 | 23-5727 | screw | | |
| 13 | 07-3134 | inner part of wall case | | |
| 14 | 14-5973 | cap | | |
| 15 | 07-0886 | cover plate | | |
| 16 | 23-5715 | screw | | |
| 17 | 23-5738 | screw | | |
| 18 | 49-2032 | disc | | |
| 19 | 14-5578 | connection duct | | |
| 20 | 07-8262 | front panel | | |
| 21 | 20-7267 | side panel | | |
| 22 | 07-8274 | front panel | | supplied with parts 23-26 |
| 23 | 28-2249 | ring | | |
| 24 | 98-1746 | packingring | | |
| 25 | 16-1225 | inspection glass | | |
| 26 | 23-5748 | screw | | |
| 27 | 98-0765 | packingring | | |
| 28 | 98-0766 | packingring | | |
| 29 | 17-8427 | cap | | |
| 30 | 07-9921 | lateral panel | left | |
| 31 | 07-9920 | lateral panel | right | supplied with part 32 |
| 32 | 08-8620 | fastening set | | supplied with part 33 |
| 33 | 07-0351 | screw | | |
| 34 | 29-4012 | top door | | supplied with parts 35-37,39 |
| 35 | 17-0356 | door magnet | | slide on version from 04/95 |
| | 07-0355 | door magnet | | screwed type |
| 36 | 15-8207 | nut | | |
| 37 | 23-5748 | screw | | |
| 38 | 29-4013 | bottom door | | supplied with parts 35-37,39 |
| 39 | 12-4870 | bush | | |
| 40 | 07-5461 | covering plate | | |
| 41 | 13-3799 | screw | M 8 x 4 | knurled |
| | 23-5715 | screw | 4,8 x 9,5 | sheet metal (from 04/95) |


Main component 07 Air/Flue duct assembly
VC 112,142,182,242,282 E, VCW 242,282 E



Main component 07 Air/Flue duct assembly VC 112,142,182,242,282 E, VCW 242,282 E

| Pict. No. | Article-No. | Part | Indic. | Type, Remarks |
|-----------|-------------|-----------------------|------------|--|
| 1 | 07-2324 | cap | | 112,142 (supplied with part 24) |
| | 07-2341 | cap | | 182 |
| | 07-2342 | cap | | 242 |
| | 07-2362 | cap | | 282 |
| 2 | 23-5715 | screw | | |
| 3 | 07-0338 | disc | | |
| 4 | 07-5546 | covering plate | | 112 |
| | 07-5547 | covering plate | | 142 |
| | 07-5548 | covering plate | | 182 |
| | 07-5549 | covering plate | | 242,282 |
| 5 | 98-0883 | packingring | | |
| 6 | 29-2208 | ring | | |
| 7 | 50-0046 | screw | | |
| 8 | 05-0518 | fan proving switch | | |
| 9 | 08-6391 | support | | |
| 10 | 23-5748 | screw | | |
| 11 | 10-5754 | screw | | 112,142 (fan proving switch fixed from outside) |
| | 23-5727 | screw | | 182,242,282 (fan proving switch fixed from inside) |
| 12 | 25-5855 | cable tree | | |
| 13 | 08-0369 | hose | | |
| 14 | 08-0831 | connection | | } only for 182,242,282 |
| 15 | 98-0202 | packingring | | |
| 16 | 11-4848 | nut | | |
| - | 98-0766 | packingring | | tube inlet for 112,142 (not shown) |
| 17 | 19-0123 | flue fan | | 112,142 (supplied with part 18) |
| | 19-0122 | flue fan | | 182,242,282 (supplied with part 18) |
| 18 | 98-0891 | packingring | | 112,142 |
| | 98-0884 | packingring | | 182,242,282 |
| 19 | 07-8409 | clip | | } fan bracket for 182,242,282 |
| 20 | 11-8885 | screw | | |
| 21 | 06-0014 | spring ring | | |
| 22 | 28-2512 | collar | Ø 63x22 | |
| 23 | 11-6669 | flue connection elbow | | |
| 24 | 01-0082 | screw | | only for 112,142 |
| 25 | 23-5740 | screw | | fan bracket for 112,142 |
| 26 | 25-5855 | cable tree | | |
| 30 | 28-4841 | elbow | | |
| 31 | 28-2515 | collar | Ø 95,5x25 | |
| 32 | 28-2513 | collar | Ø 95,5x55 | |
| 33 | 14-7022 | finishing ring | (internal) | |
| 34 | 14-5958 | flue gas duct | | |
| 35 | 19-2901 | tube | | |
| 36 | 14-7024 | finishing ring | (external) | |
| 37 | 07-3647 | protection grill | | |
| | 07-3666 | | | acc. 9000, storm guard |
| 38 | 23-5744 | screw | | |
| 39 | 50-0046 | screw | | |
| 40 | 19-4119 | reduction piece | | only for 112,182 |
| - | - | safety guard | not shown | acc. 9308 |


**Main component 07 Wallcase
VC-VCW 221 T**



Main component 07 Wallcase VC-VCW 221 T

| Pict. No. | Article-No. | Part | Indic. | Type, Remarks |
|-----------|-------------|-----------------------|-----------|-------------------------------------|
| 1 | 49-2032 | disc | | |
| 2 | 07-3110 | inner part | 98 mm | 4 inchs Acc. 251 |
| | 07-3112 | inner part | 131 mm | 5 inchs Acc. 252 |
| | 07-3114 | inner part | 221 mm | 8 inchs Acc. 253 |
| | 07-3126 | inner part | 311 mm | 12 inchs (without support) Acc. 254 |
| | 07-3116 | inner part | 311 mm | 12 inchs (with suport) Acc. 255 |
| 3 | 08-6527 | support | | |
| 4 | 11-4848 | nut | | |
| 5 | 19-1350 | disc | | |
| 6 | 21-2718 | nut | | |
| 7 | 08-6103 | support | | |
| 8 | 20-2612 | screw | | |
| 9 | 95-0237 | nut | | |
| 10 | 08-4848 | tie rod | | |
| 11 | 95-0237 | nut | | |
| 12 | 28-4030 | disc | | |
| 13 | 14-5574 | duct | 95 mm | 4 inchs Acc. 251 |
| | 14-5575 | duct | 140 mm | 5 1/2 inchs Acc. 252 |
| | 14-5576 | duct | 230 mm | 9 inchs Acc. 253 |
| | 14-5577 | duct | 320 mm | 12 1/2 inchs Acc. 254,255 |
| 14 | 07-3019 | exterior part | 85 mm | 3 inchs Acc. 251 |
| | 07-3010 | exterior part | 130 mm | 5 inchs Acc. 252,253,254 |
| | 07-3021 | exterior part | 310 mm | 12 inchs Acc. 255 |
| 15 | 14-5516 | duct | 57 mm | 2 inchs Acc. 252,253,254 |
| | 14-5518 | duct | 237 mm | 9 inchs Acc. 255 |
| 16 | 07-3662 | protection grill | | supplied with parts 17,18 |
| 17 | 12-4835 | bush | | |
| 18 | 11-5520 | safety disc | | |
| 19 | 28-2822 | sealing profile | | |
| 20 | 15-8209 | nut | | |
| 21 | 28-6401 | locking nut | | |
| 22 | 07-0340 | screw | | |
| - | - | low level safty guard | not shown | acc. 000296 (520 mm) |


Main component 07 Vertical air/flue duct assembly
VC 112,142,182,242,282 E, VCW 242,282 E
(Acc.-no. 9293,9020,9056,9076,9077)



**Main component 07 Vertical air/flue duct assembly
 VC 112,142,182,242,282 E, VCW 242,282 E
 (Acc.-no. 9293,9020,9056,9076,9077)**


| Pict. No. | Article-No. | Part | Indic. | Type, Remarks |
|-----------|-------------|-------------------|-------------|---|
| 1 | 17-8446 | cap | | |
| 2 | 20-8521 | reduction piece | Ø 47 | |
| | 20-8523 | reduction piece | Ø 56,5 | |
| 3 | - | pipe | | only available as part of Acc.-no. 9077 |
| 6 | 28-2516 | collar | 95,5 Ø x 55 | |
| 8 | 28-2526 | collar | 95,5 Ø x100 | |
| 9 | 18-8668 | bush | | |
| 10 | 25-9955 | cap | | |
| 11 | - | pitched roof tile | | only available as part of Acc.-no. 9076 |
| 12 | 15-4146 | bow | | |
| 13 | 23-5750 | screw | | |
| 14 | 28-4897 | elbow | | |
| 15 | 98-0883 | packingring | | |
| 16 | - | flat roof tile | | only available as part of Acc.-no. 9056 |
| 17 | 19-4125 | reducing piece | | only necessary if pos. 10 has a diametre of 133 mm. |
| 18 | - | elbow | | only available as part of Acc.-no. 9293 |

Main component 08



| | Page |
|--|-------------|
| Connection parts VC 110 T, 112,142 E | 72 - 73 |
| Connection parts VC 180-242,282, VCW 221-282 | 74 - 77 |
| Connection piping VC 110,180,221,240 T | 78 - 79 |
| Connection piping VC 112,142,182,242,282 E | 80 - 81 |
| Connection piping VCW 221,240,280 T | 82 - 83 |
| Connection piping VCW 242,282 E | 84 - 85 |
| Acc.-connection parts VC 110-282, VCW 180-282 | 86 - 87 |


Main component 08 Connection parts
VC 110T, 112,142 E



Main component 08 Connection parts VC 110 T, 112,142 E

| Pict. No. | Article-No. | Part | Indic. | Type, Remarks |
|-----------|-------------|-------------------------------------|--------|-------------------------------|
| 1 | 08-9127 | connecting tube | | supplied with part 2 |
| 2 | 98-0149 | o-ring | | |
| 3 | - | pump | | see main component 08 |
| 4 | 08-9108 | connecting tube | | only for 110 |
| 5 | 06-1707 | automatic de-aerator | | supplied with part 6 |
| 6 | 98-0287 | packingring | | |
| 7 | 08-9105 | connecting tube | | |
| 8 | 10-5760 | screw | | |
| 9 | 12-6153 | spring | | |
| 10 | 08-1056 | connection | | supplied with part 11 |
| 11 | 98-2409 | packingring | | |
| 12 | - | heat exchanger | | see main component 06 |
| 13 | 08-1054 | connection | | supplied with part 11 |
| | 14-0015 | de-aeration screw | | supplied with part 21 |
| 14 | 25-2805 | ntc-sensor | | |
| 15 | 12-6158 | retaining bracket | | |
| 16 | 08-9125 | connecting tube | | supplied with part 17 |
| 17 | 98-0287 | packingring | | |
| 18 | - | expansion vessel | | see main component 18 |
| 19 | 08-9106 | connecting tube | | |
| 20 | 14-0015 | de-aeration screw | | supplied with part 21 |
| 21 | 98-2459 | packingring | | |
| 22 | - | gas section | | see main component 05 |
| 23 | 08-9168 | connecting tube | | |
| 24 | 98-2497 | packingring | | |
| 25 | 08-4945 | connection piece | | |
| 26 | 15-0216 | spill valve | | |
| 27 | 08-9107 | connecting tube | | |
| 28 | 08-2564 | gas connection | | supplied with part 29 |
| 29 | 98-2489 | packingring | | |
| 30 | 07-0361 | screw | | |
| 31 | 11-1458 | disc | | |
| 32 | 08-3408 | connection piece | | B (supplied with parts 33,34) |
| 33 | 11-1328 | sleeve nut | | |
| 34 | 98-0410 | packingring | | |
| 35 | 08-2741 | gas shut-off valve | | H |
| 37 | 11-1214 | sleeve nut | | |
| 38 | 98-0471 | reducing olive | | |
| 39 | 98-1511 | packingring | | |
| 40 | 98-1508 | packingring | | |
| 41 | 98-0212 | packingring | | |
| 42 | 25-4693 | resistance | | |
| 43 | - | not necessary for british execution | | |
| 44 | 25-1822 | safety switch | | 112,142 E |
| | 25-1851 | safety switch | | 110 T |
| 45 | 25-5730 | cable,cpl. | | |
| 46 | - | not necessary | | see pict.-no. 1, 08-9127 |
| 47 | 12-8515 | filter | | |
| 48 | 98-0261 | packingring | | |
| 49 | 07-1873 | cover | | supplied with part 48 |

Main component 08 Connection parts
VC 180-242,282, VCW 221-282




02 - 08 - 010 - 01

Main component 08 Connection parts

VC 180-242,282, VCW 221-282

| Pict. No. | Article-No. | Part | Indic. | Type, Remarks |
|-----------|-------------|---|--------|---|
| 1 | - | water valve | | see main component 01 } VCW... |
| 2 | 08-3746 | cold water tube,cpl. | | |
| 3 | 08-1415 | connecting tube | | |
| 4 | 08-1314 | connecting tube | | VCW 221,240 VCW 242,282 (enlarged with part 35) VCW 280 |
| | 08-9156 | connecting tube | | |
| | 08-9130 | connecting tube | | |
| 5 | 25-2805 | ntc-sensor | | see main component 06 } VCW... supplied with part 9 |
| 6 | - | heat exchanger -d.h.w. | | |
| 7 | 08-1315 | connecting tube | | |
| 8 | 14-0015 | de-aeration screw | | |
| 9 | 98-2459 | packingring | | |
| 10 | - | connection tube | | see pict.-no. 47 (VCW) or. 49 (VC) |
| 11 | 98-1506 | packingring | | |
| 12 | 98-2495 | packingring | | |
| 13 | 15-0216 | spill valve | 2,5 m | 180-242,282 |
| | 15-0217 | spill valve | 3,5 m | 280 |
| | 15-0218 | spill valve | 1,7 m | special return |
| 14 | 08-1058 | connection | | |
| 15 | 07-0361 | screw | | |
| 16 | 11-1458 | disc | | |
| 17 | 08-1316 | connecting tube | | 180,240,280 (221 see main component 06) |
| | 08-9155 | connecting tube | | 182,242,282 (extended with part 35) |
| 18 | - | pump | | see main component 16 |
| 19 | 08-1317 | connecting tube | | |
| 20 | 06-1707 | automatic de-aerator | | supplied with part 21 |
| 21 | 98-0287 | packingring | | |
| 22 | 08-1320 | connection tube | | VC... |
| 23 | - | Hydraulically controlled diverter valve | | VCW... (see main component 01) |
| 24 | 08-2557 | gas connection | | 180-242 } supplied with part 25 280,282 } |
| | 08-2556 | gas connection | | |
| 25 | 98-2489 | packingring | | |
| 26 | 23-5727 | screw | | |
| 27 | 08-0074 | connection piece | | |
| 28 | 08-0184 | brass olive | | |
| 29 | 08-0177 | nut | | |
| 30 | 08-2741 | gas shut-off valve | 15 mm | H (180-242) |
| | 08-2745 | gas shut-off valve | 22 mm | H (280,282) |
| 31 | 98-1511 | packingring | | |
| 32 | 98-1508 | packingring | | |
| 33 | 98-1602 | packingring | | |
| 34 | 98-1609 | packingring | | |

Main component 08 Connection parts
VC 180-242,282, VCW 221-282




02 - 08 - 010 - 01

Main component 08 Connection parts

VC 180-242,282, VCW 221-282

| Pict. No. | Article-No. | Part | Indic. | Type, Remarks |
|-----------|-------------|--|--------|--|
| 35 | - - - | connection connection connection | | VC 182,242,282 (not necessary see pict.-no. 49 or 17) VCW 182,242,282 (not necessary see pict.-no. 4 or 17) VC-VCW 221 (see main component 06) |
| 36 | 25-1822 | safety switch | | VC 182,242,282 E, VCW 242,282 E |
| | 25-1851 | safety switch | | VC 180,221,240 T, VCW 221,240,280 T |
| 37 | 25-5730 | cable,cpl. | | only VC-VCW... E |
| | 17-1165 | thermo-couple | | only 180,240,280 T |
| | 17-1181 | thermo-couple | | only 221 T |
| 38 | 08-9526 | connection line | | only 180,240,280 T |
| | 17-1181 | thermo-couple | | only 221 T |
| 39 | 13-7439 | tube | | 180-242 |
| | 12-4370 | tube | | 280,282 |
| 40 | 18-1025 | expansion vessel | | |
| 41 | 08-4298 | flow switch conduction | | |
| 42 | 13-6313 | nipple | | |
| 43 | 25-1852 | safety switch | | } only VCW... |
| 44 | 95-0119 | screw | | |
| 45 | 25-5726 | cable | | |
| 46 | 08-9569 | connection line | | |
| 47 | 08-9159 | connecting tube | | VCW... |
| 48 | 98-0287 | packingring | | |
| 49 | 08-9236 | connecting tube | | VC 180,221,240,280 T |
| | 08-9237 | connecting tube | | VC 182,242,282 E |


Main component 08 Connection piping VC 110,180,221,240 T



**Main component 08 Connection piping
VC 110,180,221,240 T**

| Pict. No. | Article-No. | Part | Indic. | Type, Remarks |
|-----------|-------------|------------------------|--------|---------------|
| 1 | 08-8922 | flow switch connection | | 110 |
| | 08-8916 | flow switch connection | | 180,221,240 |
| 2 | 08-8924 | flow switch connection | | 110 |
| | 08-8910 | flow switch connection | | 180,221,240 |

Main component 08 Connection piping
VC 112,142,182,242,282 E




T = Thread connection
P = Plug-in connection

**Main component 08 Connection piping
VC 112,142,182,242,282 E**

| Pict. No. | Article-No. | Part | Indic. | Type, Remarks |
|-----------|-------------|------------------------|--------|---------------|
| 1 | 08-8914 | flow switch connection | | 112,142 |
| | 08-8918 | flow switch connection | | 182,242,282 |
| 2 | 08-8908 | flow switch connection | | 112,142 |
| | 08-8920 | flow switch connection | | 182,242,282 |

Main component 08 Connection piping
VCW 221,240,280 T




T = Thread connection
P = Plug-in connection

Main component 08 Connection piping

VCW 221,240,280 T

| Pict. No. | Article-No. | Part | Indic. | Type, Remarks |
|-----------|-------------|------------------------|--------|---|
| 1 | 08-4253 | flow switch connection | | |
| 2 | 08-4247 | flow switch connection | | |
| 3 | 08-4245 | flow switch connection | | for diverter valve with throttle piece |
| 4 | 08-8940 | flow switch connection | | for diverter valve without throttle piece |
| 5 | 08-8939 | flow switch connection | | |
| | 10-9914 | plug | | |

Main component 08 Connection piping VCW 242,282 E




T = Thread connection
P = Plug-in connection

Main component 08 Connection piping VCW 242,282 E

| Pict. No. | Article-No. | Part | Indic. | Type, Remarks |
|-----------|-------------|------------------------|--------|---|
| 1 | 10-9914 | plug | | |
| 2 | 08-8906 | flow switch connection | | |
| 3 | 08-8912 | flow switch connection | | |
| 4 | 08-4263 | flow switch connection | | |
| 5 | 08-4266 | flow switch connection | | |
| 6 | 08-4245 | flow switch connection | | for diverter valve with throttle piece |
| | 08-8940 | flow switch connection | | for diverter valve without throttle piece |
| 7 | 08-8939 | flow switch connection | | |


Main component 08 Acc.-connection parts
VC 110-282, VCW 180-282



**Main component 08 Acc.-connection parts
VC 110-282, VCW 180-282**

| Pict. No. | Article-No. | Part | Indic. | Type, Remarks |
|-----------|-------------|-----------------------|--------|--|
| 1 | 08-0177 | nut | | |
| 2 | 08-0184 | brass olive | | |
| 3 | 95-0272 | nut | | |
| 4 | 08-1714 | cold water connection | | supplied with parts 5,6 |
| 5 | 98-1605 | packingring | | |
| 6 | 95-0057 | upper part of valve | | |
| 7 | 14-3981 | knob | | |
| 8 | - | no more available | | see pict.-no. 6 |
| 9 | 98-1508 | packingring | | |
| 10 | 98-1511 | packingring | | |
| 11 | 98-0410 | packingring | | |
| 12 | 11-1328 | sleeve nut | | |
| 13 | 98-2459 | packingring | | |
| 14 | 14-0015 | de-aeration screw | | |
| 15 | 19-0721 | pressure relief valve | | |
| 16 | - | - | | not available as spare part see acc.-no. 9326 or 9327 see acc.-no. 9326 (return) or 9327 (flow) |
| 17 | 08-0945 | water connection | | |
| 18 | 08-1144 | water connection | | |
| 19 | 08-0537 | nut | | |
| | | | | <p>Note: Connetion complete VC... acc.-no. 009745 VCW... acc.-no. 009313</p> |

Main component 13



Control box
VC 110,180,221,240 T, VCW 221,240,280 T
Control box
VC 112,142,182,242,282 E, VCW 242,282 E
Flue sensor
VC 110,180,240 X H, VCW 240,280 X H

Page


90 - 93

94 - 97

98 - 99

Main component 13 Control box

VC 110,180,221,240 T, VCW 221,240,280 T




Main component 13 Control box

VC 110,180,221,240 T, VCW 221,240,280 T

| Pict. No. | Article-No. | Part | Indic. | Type, Remarks |
|-----------|-------------|------------------------|--------------|--|
| 1 | - | PCB housing | | not available as a spare part |
| 2 | 07-1775 | plastic cover | | |
| 3 | - | control box cover | | not available as a spare part |
| 4 | 10-5780 | screw | | |
| 5 | 09-0034 | safety disc | | |
| 6 | 13-9211 | screw | | |
| 8 | 14-3967 | knob | | |
| 9 | 13-0247 | printed circuit | motherboard | VC... (supplied with parts 10-12) |
| | 13-0240 | printed circuit | motherboard | VCW... (supplied with parts 10-12) } non hybrid |
| 10 | - | fuse holder | | not available as a spare part |
| 11 | 13-0037 | fuse (2.0 A/250 V) | | |
| 12 | 25-1920 | fuse | 0,16 A | |
| 14-18 | 07-1788 | cover | | supplied with parts 4,5 |
| 19 | 16-0108 | diaphragm pump | | supplied with part 21 |
| 20 | 08-0368 | hose | | |
| 21 | 13-7286 | plug | | |
| 22 | 21-0654 | insulation plate | | |
| 23 | 28-7418 | transformer | | |
| 24 | 23-5740 | screw | | |
| 25-26 | 20-1835 | cable bushing | | |
| 27 | 20-1848 | cable holder | | |
| 28 | 20-1849 | cable holder | | |
| 29 | 18-8627 | clamp | | |
| 30 | 14-0012 | screw | | |
| 31 | 12-0020 | contact protection | | |
| 32-34 | 10-5814 | screw | | |
| 35 | 13-0012 | screw | | |
| 36 | 07-0010 | screw | M5 x 9 | |
| | 23-5755 | screw | 4,8 x 13 x 8 | |
| 37 | 11-5507 | safety disc | | |
| 38 | 21-3364 | back panel | | 180,240,280 |
| 39a | 08-6386 | support | | 110 |
| 39b | 08-6405 | support | | 180,221,240,280 |
| 40a | 09-0011 | support | | 110 |
| 40b | 18-8626 | clamp | | 180,221,240,280 |
| 41 | 09-1060 | piezo ignition | | |
| 42 | 23-5727 | screw | | |
| 43 | 10-1542 | thermometer | | } glass not available seperatley as a spare part |
| 44 | 10-1250 | manometer | | |
| 45 | 08-4280 | flow switch connection | | 110 |
| | 08-4256 | flow switch connection | | 180,221,240,280 |
| 46 | 18-8624 | clamp | | |
| 47 | 11-8873 | screw | | |

Main component 13 Control box


VC 110,180,221,240 T, VCW 221,240,280 T



Main component 13 Control box
VC 110,180,221,240 T, VCW 221,240,280 T

| Pict. No. | Article-No. | Part | Indic. | Type, Remarks |
|-----------|-------------|---------------------------------|-------------|---|
| 51 | 13-0242 | printed circuit | | link |
| 52 | 25-2945 | electronic board | thermostat | non hybrid |
| 60 | - | not necessary | | |
| 61 | - | control box cover | | not available as a spare part |
| 62 | 13-0323 | printed circuit | motherboard | VC... hybrid (supplied with parts 10-12) |
| | 13-0324 | printed circuit | motherboard | VCW... hybrid (supplied with parts 10-12) |
| 63 | 25-2957 | electronic board | thermostat | hybrid |
| 64 | 25-5807 | cable tree | | VC... |
| | 25-5863 | cable tree | | VCW... |
| 65 | 25-0798 | cable tree | | pump |
| 66 | 07-0338 | disc | | |
| 67-68 | - | not necessary for (T) execution | | |

Main component 13 Control box
VC 112,142,182,242,282 E, VCW 242,282 E




Main component 13 Control box

VC 112,142,182,242,282 E, VCW 242,282 E

| Pict. No. | Article-No. | Part | Indic. | Type, Remarks |
|-----------|-------------|------------------------|--------------|--|
| 1 | - | PCB housing | | not available as a spare part |
| 2 | 07-1775 | plastic cover | | |
| 3 | - | control box cover | | not available as a spare part |
| 4 | 10-5780 | screw | | |
| 5 | 09-0034 | safety disc | | |
| 6 | 13-9211 | screw | | |
| 7 | 25-0626 | control lamp | | |
| 8 | 14-3967 | knob | | |
| 9 | 13-0272 | printed circuit | motherboard | VC... (supplied with parts 11,12) } non hybrid VCW... (supplied with parts 11,12) } |
| | 13-0277 | printed circuit | motherboard | |
| 11 | 13-0037 | fuse (2.0 A/250 V) | | |
| 12 | 25-1920 | fuse | 0,16 A | |
| 13 | 49-2147 | screw | | |
| | 28-0217 | clip | | not shown |
| 14-18 | 07-1788 | cover | | supplied with parts 4,5 |
| 19 | 16-0108 | diaphragm pump | | supplied with part 21 |
| 20 | 08-0368 | hose | | |
| 21 | 13-7286 | plug | | |
| 22 | 21-0654 | insulation plate | | |
| 23 | 28-7418 | transformer | | |
| 24 | 23-5740 | screw | | |
| 25 | 20-1835 | cable bushing | | |
| 26 | 20-1848 | cable holder | | |
| 27 | 20-1849 | cable holder | | |
| 28 | 18-8627 | clamp | | |
| 29 | 14-0012 | screw | | |
| 30 | 12-0020 | contact protection | | |
| 31-33 | 10-5814 | screw | | |
| 34 | 13-0012 | screw | | |
| 35 | 07-0010 | screw | M5 x 9 | |
| | 23-5755 | screw | 4,8 x 13 x 8 | |
| 36 | 11-5507 | safety disc | | |
| 37 | - | plate | | not available as a spare part |
| 38a | 08-6386 | support | | 112,142 |
| 38b | 08-6405 | support | | 182,242,282 |
| 39 | 23-5727 | screw | | |
| 40 | 10-1542 | thermometer | | } glass not available seperatley as a spare part |
| 41 | 10-1250 | manometer | | |
| 42 | 08-4280 | flow switch connection | | 112,142 |
| | 08-4256 | flow switch connection | | 182,242,282 |
| 43 | 09-1235 | ignition transformer | | |
| 44 | 21-0656 | insulation plate | | |
| 45 | 18-8624 | clamp | | |
| 46 | 11-8873 | screw | | |
| 47 | 06-0018 | screw | M 4x6 | |
| | 13-0005 | screw | 3,5x13 | |

Main component 13 Control box
VC 112,142,182,242,282 E, VCW 242,282 E




Main component 13 Control box

VC 112,142,182,242,282 E, VCW 242,282 E

| Pict. No. | Article-No. | Part | Indic. | Type, Remarks |
|-----------|-------------|--------------------------|-------------|--|
| 48 | 13-0451 | printed circuit board | fan | non hybrid 112,142 182 242,282 single delivery not possible, supplied with pict.-no. 51 VC... VCW... temperature limiter pump single delivery not possible VC... hybrid (supplied with parts 11,12) VCW... hybrid (supplied with parts 11,12) hybrid Notice: Prior to 31/12/90 control box cover for hybrid stamped with " HY " (see pict.-no. 61). Non hybrid no stamp. After 1/1/91 all appliances produced were hybrid models, which contained no stamp on control box cover as previos hybrid models had. |
| 49 | 25-2945 | electronic board | thermostat | |
| 50 | 10-0555 | flame supervision device | ignition | |
| 51 | 10-1384 | temperature limiter | | |
| | 10-1392 | temperature limiter | | |
| | 10-1391 | temperature limiter | | |
| 52 | 13-6936 | casing | | |
| 53 | - | casing | | |
| 54 | 20-4048 | cap | | |
| 55 | 11-8947 | screw | M 4x16 | |
| | 13-0005 | screw | 3,5x13 | |
| 56 | 25-5928 | cable tree | | |
| | 25-5929 | cable tree | | |
| 57 | 25-5803 | cable tree | | |
| 58 | 25-0798 | cable tree | | |
| 61 | - | control box cover | | |
| 62 | 13-0330 | printed circuit | motherboard | |
| | 13-0331 | printed circuit | motherboard | |
| 63 | 25-2957 | electronic board | thermostat | |


Main component 13 Flue sensor
VC 110,180,240 X H, VCW 240,280 X H



Main component 13 Flue sensor
VC 110,180,240 X H, VCW 240,280 X H

| Pict. No. | Article-No. | Part | Indic. | Type, Remarks |
|-----------|--|--|----------------------------|---|
| 1 | 07-4945 07-4920 07-4921 07-4940 | draft diverter draft diverter draft diverter draft diverter | | 110 180 240 280 |
| 2 | 25-3516 25-3511 | flue sensor flue sensor | | VC 110 VC 180,240, VCW 240,280 } supplied with parts 3-5 |
| 3 | 23-5750 | screw | | |
| 4 | 95-0239 | disc | | |
| 5 | 18-8638 | clamp | | |
| 6 7-8 | 08-9445 - | connection line not necessary for british execution | | |
| 9 | 13-0311 | printed circuit | | flue sensor |
| 10 | 13-0323 13-0324 | printed circuit printed circuit | motherboard motherboard | VC... hybrid VCW... hybrid |

Main component 16




Pump
VC 110-242,282, VCW 221-282

Page

102 - 103

Main component 16 Pump
VC 110-242,282, VCW 221-282




Main component 16 Pump

VC 110-242,282, VCW 221-282

| Pict. No. | Article-No. | Part | Indic. | Type, Remarks |
|-----------|-------------------------------|------------------------|--|---|
| 1 | 16-1077 16-1106 16-1107 | pump pump pump | VP 4 (240 V) VP 5 (240 V) VP 6 (240 V) | 110,112,142 (supplied with parts 4,7,9) 180-242 (supplied with parts 2-10) 280,282 (supplied with parts 2-10) |
| 2-3 | - | - | | single delivery not possible, supplied with 16-1108 or 16-1109 |
| 4 | 25-1329 25-1370 | condenser condenser | 2,5 μ F 3 μ F | 110,112,142 180-282 |
| 5 | - | - | | single delivery not possible, supplied with 16-1108 or 16-1109 |
| 6 | 06-0009 | screw | | |
| 7 | 98-1511 | packingring | | |
| 8 | 13-6333 | nipple | | |
| 9 | 98-1508 | packingring | | |
| 10 | 98-0222 | packingring | | |

Main component 18




Expansion vessel
VC 110,112,142
Expansion vessel
VC 180-282, VCW 221-282

Page

106 - 107

108 - 109

Main component 18 Expansion vessel
VC 110,112,142




**Main component 18 Expansion vessel
VC 110,112,142**

| Pict. No. | Article-No. | Part | Indic. | Type, Remarks |
|--------------|-------------|------------------|--------|---------------|
| 1 | 18-1005 | expansion vessel | | |
| 2 | 98-1508 | packingring | | |
| 3 | 23-5727 | screw | | |

Main component 18 Expansion vessel

VC 180-282, VCW 221-282



**Main component 18 Expansion vessel
VC 180-282, VCW 221-282**

| Pict. No. | Article-No. | Part | Indic. | Type, Remarks |
|-----------|--------------------|--------------------------------------|-------------------|---|
| 1 | 18-1022 18-1030 | expansion vessel expansion vessel | 12 ltr. 8 ltr. | supplied with parts 2,3 from 05/95 (CE marked) |
| 2 | - | - | | single delivery not possible, supplied with 18-1022 |
| 3 | 98-2495 | packingring | | |